

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

TOYOTA/LEXUS	2	KIA	34
NISSAN/INFINITI.....	3	SSANGYONG.....	35
HONDA/ACURA	7	MAHINDRA.....	50
MITSUBISHI	9	ASIAN TRUCKS.....	56
MAZDA	10	MG.....	56
DAIHATSU	11	CHERY	56
SUBARU	11	BYD.....	57
ISUZU.....	11	ETC	59
HINO.....	13		
FUSO.....	13		
AUDI/VW/SEAT/SKODA.....	13		
FORD/Lincoln/Mercury	14		
RENAULT/DACIA/SAMSUNG.....	14		
BMW/MINI	17		
LAND ROVER	17		
JAGUAR.....	21		
MERCEDES BENZ.....	21		
FIAT/ALFA ROMEO/LANCIA	24		
PEUGEOT/CITROEN	26		
VOLVO	30		
CHRYSLER/JEEP/DODGE.....	31		
OPEL/VAUXHALL	31		
HOLDEN	34		
HYUNDAI/GENESIS/SEASALL	34		

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

TOYOTA/LEXUS

New system added

CROWN (S230)

DRS (Dynamic Rear Steering)

- Basic Function
 - DTC Analysis
 - Data Analysis
- Special Function
 - Vehicle Control History (RoB)
 - Rear Steering Motor Drive
 - Rear Toe Adjustment

Front Right Door

- Basic Function
 - DTC Analysis
 - Data Analysis
 - Actuation Test

Front Left Door

- Basic Function
 - DTC Analysis
 - Data Analysis
 - Actuation Test

Rear Left Door

- Basic Function
 - DTC Analysis
 - Data Analysis
 - Actuation Test

Rear Right Door

- Basic Function
 - DTC Analysis
 - Data Analysis
 - Actuation Test

Front Side Radar 'A'

- Basic Function
 - DTC Analysis
 - Data Analysis
- Special Function
 - Vehicle Control History (RoB)
 - Transition to Online Axis Alignment Mode
 - Front Side Radar 'A' Beam Axis Adjustment
 - Front Side Radar 'A' Beam Axis Display
 - Front Side Radar 'A' ECU Data Save
 - Front Side Radar 'A' ECU Data Write

Front Side Radar 'B'

- Basic Function
 - DTC Analysis
 - Data Analysis

- Special Function
 - Vehicle Control History (RoB)
 - Transition to Online Axis Alignment Mode
 - Front Side Radar 'B' Beam Axis Adjustment
 - Front Side Radar 'B' Beam Axis Display
 - Front Side Radar 'B' ECU Data Save
 - Front Side Radar 'B' ECU Data Write

ITS Connect

- Basic Function
 - DTC Analysis
 - Data Analysis
- Special Function
 - Vehicle Control History (RoB)
 - Navigation System Type Learning

New model added

4RUNNER (N210)

- Engine and ECT
- Cruise Control
- Air suspension
- ABS/VSC/TRAC
- Tire Pressure Monitor
- Immobiliser
- Theft Deterrent
- SRS Airbag
- Body
 - Back Door
 - Occupant Detection

AVENSIS (T270)

- Engine and ECT
- Cruise Control
- ABS/VSC/TRC
- Tire Pressure Monitor
- EMPS
- Electric Parking Brake
- PCS/LDA/RSA/LVN
- Air Conditioner
- Immobiliser
- Theft Deterrent
- SRS Airbag
- Main Body
 - PM1 Gateway
 - PM2 Gateway
 - D-Door Motor
 - P-Door Motor
 - RL-Door Motor
 - RR-Door Motor
 - Driver Seat
 - Master Switch
 - Sliding Roof
 - Tilt&Telescopic
 - Combination Meter
 - AFS

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

- HL AutoLeveling
- Entry&Start
- Power Source Control
- Charging Control
- Starting Control
- Navigation System

CROWN SEDAN / COMFORT (XS10)

- Engine
- Stop and Start
- ABS/VSC/TRC(TRAC)
- SRS Airbag
- Combination Meter

GRAND HIGHLANDER (AS10)

- Engine
- Transmission
- Hybrid Control
- Motor Generator
- Rear Motor Generator
- Brake/EPB
- Brake Booster
- Tire Pressure Monitor
- EMPS
- Front Recognition Camera
- Circumference Monitoring Camera Control Module
- Steering Angle Sensor
- Driver Monitor Camera Control
- Rear Camera
- Air Conditioner
- SRS Airbag
- Main Body
- Central Gateway
- Back Door
- Driver Seat
- Combination Meter
- Digital Rear-View Mirror
- Clearance Warning
- Entry and Start
- Power Source Control
- Navigation System
- Front Radar Sensor
- Front Side Radar 'A'
- Front Side Radar 'B'
- Blind Spot Monitor 'B'
- Blind Spot Monitor 'A'
- Acoustic Vehicle Alerting System
- Sub Battery System
- Active Noise Control
- Power Integration No.1
- Power Distribution Box
- Telematics

NISSAN/INFINITI

New system added

E-HUD

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

Driver Monitor Camera

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

HD MAP DATA MODULE

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

TCU for HD MAP DATA

- Basic Function
- DTC Analysis
- ECU Information Display

CAN monitor unit

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

New type added

ENGINE

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

EV/HEV

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information Display
- Special Function
- Clutch 1 position learning

Motor Control

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

[Back to Index](#)

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

Rear Motor Control

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

HV Battery

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

Brake

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

Shift

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

EPS

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

IPDM Engine Room

- Basic Function
- DTC Analysis
- ECU Information Display

Meter

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

HVAC

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

ICC/ADAS2

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

VSP

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

IVC

- Basic Function
- DTC Analysis
- ECU Information Display

ALH

- Basic Function
- DTC Analysis
- ECU Information Display

Side Radar (Front left)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

Side Radar (Front right)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

WL CHG

- Basic Function
- DTC Analysis
- ECU Information Display

HL ECU LH

- Basic Function
- DTC Analysis
- ECU Information Display

HL ECU RH

- Basic Function
- DTC Analysis
- ECU Information Display

AT/CVT

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

ABS

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information Display

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

AIRBAG

- Special Function
Collision Detection Enabled(Airbag Activate)

AVM

- Basic Function
DTC Analysis
Data Analysis
Actuation Test
ECU Information Display
- Special Function
Predictive Course Line Display
Steering Angle Sensor Adjustment
MOD Function
Parts With Door Mirror Auto Fold Function
Non-Viewable Area Reminder
Initialze Camera Image Calibration
Select Language of Warning Message
Turning Radius Correction

Side radar (Rear left)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

Side radar (Rear left)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

Laser/Radar(DoIP)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
- Special Function
Milliwave Radar Adjust

ICC/ADAS2

- Basic Function
DTC Analysis
Data Analysis
Actuation Test
ECU Information Display

4WD(e-4WD/All Mode AWD)

- Special Function
Start Calibration
Lock Sleeve Sensor Initialze
Lock Sleeve Sensor Learning
Oil Deterioration INFO Reset

CHASSIS CONTROL

- Basic Function
DTC Analysis
Data Analysis
Actuation Test
ECU Information Display
- Special Function
Erase Last Driver Information
Erase Key Allotement User
Erase Personal Setting
Cause of Auto-Cancel 1

ICC_ADAS

- Basic Function
DTC Analysis
Data Analysis
Actuation Test
ECU Information Display
- Special Function
Steering Torque Calibration

EV/HEV(DoIP)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

HV BATTERY(DoIP)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

HV BATTERY2(DoIP)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

Motor Control(DoIP)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

Rear Motor Control(DoIP)

- Basic Function
DTC Analysis
ECU Information Display

Charger/PD Module(DoIP)

- Basic Function
DTC Analysis
ECU Information Display

Brake(DoIP)

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

- Basic Function
DTC Analysis
ECU Information Display

Shift(DoIP)
- Basic Function
DTC Analysis
ECU Information Display

ABS(DoIP) Airbag
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

EPS(DoIP) Airbag
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

BCM(DoIP)
- Basic Function
DTC Analysis
ECU Information Display

IPDM Engine Room(DoIP)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

Meter(DoIP)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

ICC/ADAS2(DoIP)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

Multi AV(DoIP)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

Auto Back Door(DoIP)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

Lane Camera(DoIP)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

Sonar(DoIP)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

8ch CAN Gateway 2(DoIP)
- Basic Function
DTC Analysis
ECU Information Display

Chassis Control (DoIP)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

Laser/Radar(DoIP)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

AVM (DoIP)
- Basic Function
DTC Analysis
ECU Information Display

VSP(DoIP)
- Basic Function
DTC Analysis
ECU Information Display

Side radar (Rear left) (DoIP)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

Side radar (Rear right) (DoIP)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

IVC(DoIP)
- Basic Function
DTC Analysis

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

ECU Information Display

Lithium ion battery 12V(DoIP)

- Basic Function
- DTC Analysis
- ECU Information Display

ALH(DoIP)

- Basic Function
- DTC Analysis
- ECU Information Display

Audio AMP(DoIP)

- Basic Function
- DTC Analysis
- ECU Information Display

CSCM (DoIP)

- Basic Function
- DTC Analysis
- ECU Information Display

DCDC(DoIP)

- Basic Function
- DTC Analysis
- ECU Information Display

DM CAM(DoIP)

- Basic Function
- DTC Analysis
- ECU Information Display

E-HUD(DoIP)

- Basic Function
- DTC Analysis
- ECU Information Display

Function improvement and bug fixes

ENGINE System

- DTC Clear Function improvement

System Search Bug Fixes

[Back to Index](#)

HONDA/ACURA

New function added

Odyssey_eHEV_RC5, etc

- Engine
- Special Function
- E-VTC Learning
- Sudden Acceleration Control Switching Function

ZR-V RZ6, etc

- Engine
- Special Function
- VTC TEST

ACCORD, etc

- Engine
- Special Function
- IQA Data Write (6 characters)

PILOT, MDX, etc

- AT
- Special Function
- Torque Converter Correction Value Learning
- TCM Set Up

ACCORD, etc

- CAN Gateway
- Special Function
- Communication History Reset of F-CAN Connected Units
- Synchronize the VIN
- Restart the OTA System

ODYSSEY, etc

- Immobilizer/Keyless Access/One Push Start
- Special Function
- Add 1 Key

New type added

FIT_HYBRID_GR3:, etc : JAPAN

- One Push Start_Keyless Access Control System
- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display
- Special Function
- Self Check
- Number of KEYLESS ACCESS Remotes
- History Data
- System Check 1
- System Check 2
- System Type
- Antenna level 1
- Antenna level 2
- Key Position
- Battery Voltage
- Function Test
- Keyless Access Status Log
- Customization (Japan)

Odyssey_eHEV_RC5:, etc

- BCM_Lighting
- Basic Function

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

DTC Analysis
Data Analysis
Actuation Test

BCM_Doorlocks
- Basic Function
DTC Analysis
Data Analysis
Actuation Test

BCM_Keyless
- Basic Function
DTC Analysis
Data Analysis
Actuation Test
- Special Function
Keyless Check

BCM_Security
- Basic Function
DTC Analysis
Data Analysis
Actuation Test
- Special Function
History Data Clear
History Data

BCM_Wiper
- Basic Function
DTC Analysis
Data Analysis
Actuation Test

BCM_HVAC
- Basic Function
DTC Analysis
- Special Function
HVAC Control Unit Self Test

BCM_POWER WINDOW
- Basic Function
DTC analysis
Data analysis
Actuation Test
- Special Function
Power Window Reset for Driver side
Power Window Reset for Passenger side
Power Window Reset for Left Rear
Power Window Reset for Right Rear

BCM_Active_Cornering_Light
- Basic Function
DTC analysis
Data analysis
Actuation Test

Blind Spot Information
- Basic Function
DTC Analysis
Data Analysis
Actuation Test
- Special Function
Left BSI Radar Operation Check
Right BSI Radar Operation Check

Multi View Camera System
- Basic Function
DTC analysis
Data analysis
ECU Information Display
- Special Function
Aiming Accuracy Checking Mode
Equipment Learning Value Reset

BCM_Power_Tailgate
- Basic Function
DTC analysis
Data analysis
Actuation Test

BCM_Telematics
- Basic Function
DTC analysis
Data analysis

BCM_Power Sliding Door
- Basic Function
DTC analysis
Data analysis
Actuation

BCM_Bluetooth
- Basic Function
DTC analysis
Data analysis

BCM_Wireless Charger
- Basic Function
DTC Analysis

BCM_Semiconductor Fuse
- Basic Function
DTC Analysis

Function improvement and bug fixes

Auto VIN Improved

Immobilizer/Keyless Access/One Push Start Comm. Improved

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

Engine

- Basic Function
- DTC Analysis
- Data Analysis
- Special Function
- CRANK (CKP) PATTERN LEARNING

AT/CVT

- Basic Function
- ECU Information Display

CAN Gateway

- Basic Function
- Data Analysis

IDSS

- Basic Function
- Data Analysis

- ABS/ASC/ASTC/WSS
- SRS-AIR BAG
- Air Conditioner
- ETACS (Electronic Time and Alarm Control System)
- TPMS
- Meter
- Steering Angle Sensor
- AWC
- AUDIO
- Power Gate
- KOS / IMMO / Keyless
- OSS (One touch Start System)
- CORNER SENSOR/BACK SENSOR
- EPB
- Gateway
- FCM/LDW/AHB
- BSW (Blind Spot Warning)
- BSW (SUB)

[Back to Index](#)

MITSUBISHI

New model added

OUTLANDER (GF2W)

- MPI / GDI / DIESEL
- AT / CVT / A-MT / TC-SST
- AUTO CRUISE
- 4WS / Electric Power steering
- ABS/ASC/ASTC/WSS
- SRS-AIR BAG
- Air Conditioner
- ETACS (Electronic Time and Alarm Control System)
- TPMS
- Meter
- Steering Angle Sensor
- AWC
- AUDIO
- Power Gate
- KOS / IMMO / Keyless
- OSS (One touch Start System)
- CORNER SENSOR/BACK SENSOR
- EPB
- Gateway
- FCM/LDW/AHB
- BSW (Blind Spot Warning)
- BSW (SUB)

OUTLANDER (GF3W)

- MPI / GDI / DIESEL
- AT / CVT / A-MT / TC-SST
- AUTO CRUISE
- 4WS / Electric Power steering

OUTLANDER (GF4W)

- MPI / GDI / DIESEL
- AT / CVT / A-MT / TC-SST
- AUTO CRUISE
- 4WS / Electric Power steering
- ABS/ASC/ASTC/WSS
- SRS-AIR BAG
- Air Conditioner
- ETACS (Electronic Time and Alarm Control System)
- TPMS
- Meter
- Steering Angle Sensor
- AWC
- AND
- AUDIO
- Power Gate
- KOS / IMMO / Keyless
- OSS (One touch Start System)
- CORNER SENSOR/BACK SENSOR
- ACC / FCM
- Multi around monitor
- EPB
- Gateway
- FCM/LDW/AHB
- BSW (Blind Spot Warning)
- BSW (SUB)

OUTLANDER (GF6W)

- MPI / GDI / DIESEL
- Auto Stop and Go
- AT / CVT / A-MT / TC-SST
- 4WS / Electric Power steering
- ABS/ASC/ASTC/WSS
- SRS-AIR BAG
- Air Conditioner
- ETACS (Electronic Time and Alarm Control System)

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

- TPMS
- Meter
- Steering Angle Sensor
- AWC
- AND
- AUDIO
- Power Gate
- KOS / IMMO / Keyless
- OSS (One touch Start System)
- CORNER SENSOR/BACK SENSOR
- ACC / FCM
- Multi around monitor
- EPB
- Gateway
- FCM/LDW/AHB
- BSW (Blind Spot Warning)
- BSW (SUB)

OUTLANDER (GF7W)

- MPI / GDI / DIESEL
- Auto Stop and Go
- AT / CVT / A-MT / TC-SST
- AUTO CRUISE
- 4WS / Electric Power steering
- ABS/ASC/ASTC/WSS
- SRS-AIR BAG
- Air Conditioner
- ETACS (Electronic Time and Alarm Control System)
- TPMS
- Meter
- Steering Angle Sensor
- AWC
- AND
- AUDIO
- Power Gate
- KOS / IMMO / Keyless
- OSS (One touch Start System)
- CORNER SENSOR/BACK SENSOR
- ACC / FCM
- Multi around monitor
- EPB
- Gateway
- FCM/LDW/AHB
- BSW (Blind Spot Warning)
- BSW (SUB)

OUTLANDER (GF8W)

- MPI / GDI / DIESEL
- Auto Stop and Go
- AT / CVT / A-MT / TC-SST
- AUTO CRUISE
- 4WS / Electric Power steering
- ABS/ASC/ASTC/WSS
- SRS-AIR BAG
- Air Conditioner

- Lane Keep
- ETACS (Electronic Time and Alarm Control System)
- TPMS
- Meter
- Steering Angle Sensor
- AWC
- AND
- AUDIO
- Power Gate
- KOS / IMMO / Keyless
- OSS (One touch Start System)
- CORNER SENSOR/BACK SENSOR
- ACC / FCM
- Multi around monitor
- EPB
- Gateway
- FCM/LDW/AHB
- BSW (Blind Spot Warning)
- BSW (SUB)

[Back to Index](#)

MAZDA

New function added

- BT-50 TCM
- Special Function
Transmission Characterization/Solenoid IDN

Function improved

- CX-5 PCM
- Basic Function
Data Analysis
Actuation Test

- CX-5 TCM
- Basic Function
Data Analysis

- CX-9 PCM
- Basic Function
Data Analysis

- CX-9 TCM
- Basic Function
Data Analysis

- CX-30 TCM
- Basic Function
Data Analysis

Feedback

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

Australia : MAZDA3 Engine DTC bug fixed
Australia : BT-50 Engine Special function added
Australia: CX-5 Engine Special function added
USA : CX-5 FSC Special function bug fixed
USA : CX-30 FSC Special function bug fixed

[Back to Index](#)

DAIHATSU

New model added

MOVE (LA850S/LA860S)

- EFI
- CVT
- eco IDLE
- ABS/VSC
- EPS
- Steering Angle Sensor
- SRS AIRBAG
- Body
- Combination Meter
- Combi Switch
- Auto A/C
- Auto Levelling
- Monitor Camera
- Stereo Camera
- Sonar
- PSD_RH
- PSD_LH
- Gateway

[Back to Index](#)

SUBARU

Function improvement and bug fixes

System comm. Stabilized
DTC item added
Sensor item added

[Back to Index](#)

ISUZU

New system added

PICKUP TRUCK/SUV Powertrain Interface Module

- Basic Function
 - DTC Analysis
 - Data Analysis
 - Actuation Test
 - ECU Information
- Special Function
 - VIN Programming
 - ABS Present
 - Electronic Stability Control Present
 - Air Conditioning Compressor Type
 - Engine Performance Identifier
 - Vehicle Speed Control System Type
 - Traction Control System Present
 - ECC Present
 - Automatic Transmission Present
 - EBT Usage
 - Set Point Duty Cycle Percent (Term L illumON)
 - Set Point Duty Cycle Percent (Term L illumOff)
 - Set Point Duty Cycle Percent (Term L EBT)
 - Vehicle Top Speed Limit Request
 - Transfer Case Control Module Present
 - Hill Descent Switch Present
 - Transmission Shift Pattern Switch Present

F/G Series EBS Full air

- Basic Function
 - DTC Analysis
 - Data Analysis
 - ECU Information
- Special Function
 - Initial Learning

N Series Urea SCR

- Basic Function
 - DTC Analysis
 - Data Analysis
 - Actuation Test
 - ECU Information
- Special Function
 - Dosing Test (High Injection)
 - Dosing Test (Low Injection)
 - ECU Lock

N Series CECU

- Basic Function
 - DTC Analysis
 - ECU Information
- Special Function
 - ECU Lock

N Series IO Controller

- Basic Function
 - DTC Analysis
 - ECU Information
- Special Function

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

ECU Lock

N Series HVAC

- Basic Function

DTC Analysis

ECU Information

N Series SAS

- Basic Function

DTC Analysis

ECU Information

N Series MIMAMORI

- Basic Function

DTC Analysis

ECU Information

N Series Intelligent Voltage Stabilizer

- Basic Function

DTC Analysis

ECU Information

- Special Function

ECU Lock

LV/LT Series ABS 8

- Basic Function

DTC Analysis

Data Analysis

Actuation Test

ECU Information

New function added

F/G Series 4HK1

- Special Function

ECU Lock

DPD Cooling Mode

Check DPD Differential Pressure

EGR Valve Zero Position Step Counter

New type added

PICKUP TRUCK/SUV RZ4E

F/G Series 6UZ1

- Basic Function

DTC Analysis

Data Analysis

Actuation Test

ECU Information

- Special Function

Reset Oil Dilution

Clear DPD Data (Exchange DPD Filter)

Clear Learned Value (Dew Point)

Clear Learned Value (Fuel Injection)

Clear Learned Value (Fuel Rail Pressure Regulation)

Clear Learned Value (Lambda Sensor)

Clear Learned Value (Fuel Mass Observer)

Clear Learned Value (Wheel Learning)

Clear Learned Value (Intake Throttle)

Clear Learned Value (Lambda Sensor Adaptation)

Exhaust Differential Pressure Sensor Learning

N Series RZ4E

- Basic Function

DTC Analysis

Data Analysis

Actuation Test

ECU Information

- Special Function

DPD Forced regeneration

DPD Automatic regeneration

DPD Automatic regeneration Reset

DPD Regeneration (PM Over Accumulation)

DPD Regeneration Data Reset

Engine oil exchange reset

ECU Lock

Accelerator Pedal Position (Full) Learn Value Reset

NOx Learning Reset

Lambda Learning Value Reset

Fuel Supply pump Learn Resetting

Service Management Data Reset

Baro Press Zero Learning

Exhaust Differential Pressure Sensor Learning

DPD Dry

DPD Cooling Mode

Reset Aging Factor of DOC for NO2 Produce

LNT Data Reset

PM Sensor Regeneration Count Reset

F/G Series 6UZ1

- Basic Function

DTC Analysis

Data Analysis

Actuation Test

ECU Information

- Special Function

DPD Slow regeneration

DPD Forced regeneration

Injector quantity trim

Injector programming

Program MAF Learn value

Engine oil exchange reset

VIN Programming

ECU Lock

Accelerator Pedal Position (Full) Learn Value Reset

EEPROM Error clear

MAF Learning

Check DPD Differential Pressure

EGR Valve Zero Position Step Counter

LV/LT Series Air Suspension

- Basic Function

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

DTC Analysis
Data Analysis
Actuation Test
ECU Information

- Engine
- Transmission
- DCU (Dosing Control Unit)
- Suspension
- Brake
- FCM (Front image recognition sensor)
- LDWS (Lane departure warning systems)
- VCS (Vehicle Control System)
- Air bag
- Driving support
- Meter
- Central gateway
- Central gateway (sub)
- Adaptive Driving Beam
- Automatic high beam
- Front Radar
- Door Control
- Body control module

Feedback

Australia : D-MAX Engine Special Function bug fixed
Australia : D-MAX Radar Special Function added
Australia : Immobilizer Special Function added
Australia : F/G series Engine, EBS New type added
Australia : F/G series Engine New type added
Israel : D-MAX Engine New type added
Israel : D-MAX Urea SCR bug fixed
Israel : D-MAX Engine Special Function added

[Back to Index](#)

HINO

New model added

PROFIA (2DG/2KG/2PG/2RG/2SG)

- Engine
- DCU (Dosing Control Unit)
- Suspension
- Brake
- FCM (Front image recognition sensor)
- LDWS (Lane departure warning systems)
- VCS (Vehicle Control System)
- Immobilizer
- Air bag
- Driving support
- Meter
- Body Control Module
- Central gateway
- Central gateway (sub)
- Adaptive Driving Beam

PROFIA (LDG/LKG/QKG/QDG)

- Engine
- Transmission
- DCU (Dosing Control Unit)
- Suspension
- Brake
- Scanning cruise/Lane departure warning systems/Pre-crash safety system
- LDWS (Lane departure warning systems)
- VCS (Vehicle Control System)
- Immobilizer
- Air bag
- Meter

SELEGA (2DG/2KG/2RG/2SG/2TG)

SELEGA (LDG/LKG/LJG/LNG/QPG/QRG)

- Engine
- Transmission
- DCU (Dosing Control Unit)
- Brake
- Scanning cruise/Lane departure warning systems/Pre-crash safety system
- LDWS (Lane departure warning systems)
- VCS (Vehicle Control System)
- Air bag
- Meter
- Kneeling system

[Back to Index](#)

FUSO

New system added

EURO 2/3/4

FULL AUTO A/C

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information Display

[Back to Index](#)

AUDI/VW/SEAT/SKODA

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

Missing ID added (Engine system)

- 111 ea VAG Number (Engine ID)

[Back to Index](#)

FORD/Lincoln/Mercury

Function enhanced

Transit 2.0L, 3.5L, 3.7L

Transit Connect 1.0L, 1.5L

MKZ 3.0L

Navigator, Navigator L 3.5L

- Basic Function

Data Analysis

Actuation Test

[Back to Index](#)

RENAULT/DACIA/SAMSUNG

Vehicle enhanced

LOGAN SANDERO II

CAPTUR

CAPTUR II

Megane IV

Megane IV PH2

MASTER III

KOLEOS II

CLIO V

INJECTION

- Basic Function

DTC Analysis

Data Analysis

Actuation Test

ECU Information

- Special Function

Read Configuration

Boost Pressure Sensor Programming

Start OBD test : Catalytic Converter

Parameterage Prive 264

Adaptives After Replacing Particle Filter

Vacuum Pump Operation Request

Particle Filter Pressure Diff. Sensor

Cruise control/Speed Limiter Programming

Rail Pressure Limiter

Turbocharger Programming

Downstream Oxygen Sensor Reset [RZ137]

Downstream Oxygen Sensor Reset [RZ148]

Starting Authorization

Maximum Permissible Speed

Fuel Pump Priming Complete

Exhaust Flap Low Setting

Calibrated Value For Urea Consumption

Enter injector codes

Cylinder Pressure Sensor

ADBLUE System Performance

High Pressure Pump Counter

Stop and Start Function

Upstream Oxygen Sensor Reset [RZ136]

Upstream Oxygen Sensor Reset [RZ147]

Injection Pump Adaptatives [RZ077]

EGR Valve Programming

EGR Bypass Programming

SCR Outlet Ammonia Leak Meter

Computer Reset

Waste Gate Regulation

Start OBD test : O2 Sensors

Camshaft Sensor Programming

Richness Regulation Programming

Injector Adaptives

Particle Filter Regeneration

Air Flowmeter Programming

Speed Limiter

Number Of Starting 1

Number Of Starting 2

Number Of Starting 3

Number Of Starting 4

Cylinder 1 Injector Code

Cylinder 2 injector code

Cylinder 3 injector code

Cylinder 4 injector code

Cruise Control/Speed Limiter Programming

Flywheel Target Programming [RZ037]

Flywheel Target Programming [RZ119]

Programming Throttle Limits [RZ100]

Programming Throttle Limits [RZ031]

Proportional Richness Sensor Programming

Engine Adaptives

Ignition Coil Adaptive

Stop and Start Function

Idle Air Volume Learning - Service Mode

Idle Air Volume Learning - Factory Mode

Richness Regulation Programming

Number Of Starting Cycles

Alternator Setpoint Voltage

Write Vin

Fuel Supply Prevention

Idle Stop And Start Counter

Driver Start Counter

INSTRUMENT PANEL

- Basic Function

DTC Analysis

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

Data Analysis	ECU Information
Actuation Test	
ECU Information	RADIO
- Special Function	- Basic Function
Read Configuration	DTC Analysis
ADAC Display Type	Data Analysis
Distance Unit	Actuation Test
Overspeed Function - Arabia	ECU Information
Type Pressure Units	- Special Function
Odometer in Km	Computer Configuration
Odometer in Miles	VIN write
Language Version	Computer Initialisation
Distance Units	
Consumption Measurement Units	AMPLIFIER
Gearbox Type	- Basic Function
Overspeed Alarm	DTC Analysis
External Temperature	Data Analysis
Seat Belt Reminder Buzzer	Actuation Test
Battery Charge Warning Information	ECU Information
VIN Write	- Special Function
Oil Change Interval In KM	Read Configuration
Oil Change Range : Current Value in KM	System Configuration
Update Odometer	Noise-Reducing Microphone
Oil Service Interval In Days	Amplifier Reset
Oil Change Frequency In Days	VIN write
Reset Oil Change Counter	
ABS/ESP	ABS (Anti-lock Braking System)
Cruise control/speed limiter	- Basic Function
Computer Initialisation	DTC Analysis
	Data Analysis
TCU(Telematic CTRL unit)	Actuation Test
- Basic Function	ECU Information
DTC Analysis	- Special Function
Data Analysis	Read Configuration
Actuation Test	L/H Front Wheel Solenoid Valves
ECU Information	R/H Front Wheel Solenoid Valves
- Special Function	L/H Rear Wheel Solenoid Valves
Computer Reset	R/H Rear Wheel Solenoid Valves
Emergency Call Service	Bleed Front L/H Wheel
VIN Write	Bleed Front R/H Wheel
Accelerometer	Bleed Rear L/H Wheel
Erase Computer Memory	Bleed Rear R/H Wheel
	Hill Start
VARIABLE PAS	Check target teeth
- Basic Function	Reset
DTC Analysis	Transverse acceleration offset sensor
Data Analysis	Brake pressure offset sensor
Actuation Test	Longitudinal acceleration sensor offset
ECU Information	Steering wheel angle offset sensor
- Special Function	Speedo index
VIN Write	Write Vin
	Transverse acceleration sensor
COMMUNICATIONS UNIT	Longitudinal acceleration sensor
- Basic Function	Deactivate Maintenance Mode
Actuation Test	Activate Maintenance Mode

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

Steering wheel angle sensor

EVC (Electronic Vehicle Control)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information
- Special Function
- Read Configuration
- Traction Battery Relay
- Charging Test Authorisation

LEFT HAND DOOR or PASSENGER'S SEAT

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information
- Special Function
- Front Slide Learning
- Rear Slide Learning
- Lumbar Learning
- VIN Write

BMS (Battery Monitoring System)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information
- Special Function
- Start Authorisation From BMS
- Module Change

PEB (Electric Parking Brake)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

BMS Safety

- Basic Function
- ECU Information
- Special Function
- Start Authorisation From BMS

POWER ASSISTED STEERING

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information
- Special Function

Hand Off Detection Learning
Computer Reset
VIN write

SEALED FUEL TANK

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information
- Special Function
- Hand Off Detection Learning
- Computer Reset
- VIN write

VEHICLE SOUND

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information
- Special Function
- Hand Off Detection Learning
- Computer Reset
- VIN write

BCB (Battery Charging Box)

- Basic Function
- ECU Information

UREA DOSING

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information
- Special Function
- Overall Quantity Of Adblue Injected
- Reset Of The Heating Counter Active Time
- Reset Urea Volume
- Injector Heating
- ADBLUE Module Electrical Check
- ADBLUE First Filling Test
- VIN Write
- ADBLUE Emptying Test
- ADBLUE Injector Sound Test
- ADBLUE Injector Release Test
- Flow Rate Function

AVM (Around View Monitor)

- Basic Function
- DTC Analysis
- Data Analysis
- Actuation Test
- ECU Information

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

- Special Function
- Computer Reset
- VIN write

Feedback

KOR : Latitude (SM5) – DTC Bug fixed & Enhanced
KOR : Master III – DTC Bug fixed & Enhanced
KOR : Koleos II (QM6) : Injection Sensor Data Enhanced
GEN : Duster PH3 (Journey) – Injection Function Enhanced
KOR : Talisman (SM6) – DCT Computer Programming Enhanced
KOR : Talisman (SM6) – Air Condition Function Enhanced
KOR : Koleos (QM5) – Injector Coding Enhanced
KOR : Koleos II (QM6) : Idle Air Voume Learning Enhanced
KOR : Master III – Fuel Pump Enhanced
KOR : Latitude (SM5) – Automatic Gearbox Function Enhanced

[Back to Index](#)

BMW/MINI

New function added

5 Series (G30 / G31)

DME (Digital Motor Electronics)

- Special Function
- Radiator blind
- Reset generator statistical data
- Resetting plant charging mode

SCR (Selective Catalytic Reduction)

- Special Function
- Drawing off SCR metering line until empty
- Reset: SCR switch-off scenario
- SCR control unit: Reset assembly mode
- SCR catalytic converter: Register replacement
- Display of SCR tank fill level
- SCR tank system test
- Start-up of SCR tank system

SGR48 (Starter motor generator 48 volt)

- Special Function
- Reset Starter motor generator 48 volt production mode

[Back to Index](#)

LAND ROVER

New model added

Range Rover 2024

AAM (Audio Amplifier Module)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

ABS (ABS Control Module)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display
- Special Function
- Apply Electric Park Brake
- Calibrate Electric Park Brake
- Clear Electric Park Brake End of Line Mode
- Rear Brake Pad Replacement - Exit Maintenance Mode
- Rear Brake Pad Replacement - Release To Service Position
- Release Electric Park Brake
- Set Assembly Mode State
- Test Air Volume Consumption and Fluid Leakage

BCM (Body Control Module)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display
- Special Function
- Alarm Trigger History
- Enable Protected Outputs
- Fuel Pump Enable/Disable
- Module Reset
- Rain/Light Sensor Calibration
- Roof Blind Calibration - Front

BECM (Battery Energy Control Module)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

CCM (Adaptive Speed Control Control Module)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

CHCM (Chassis Control Module)

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

- Basic Function DTC Analysis Data Analysis ECU Information Display	ECU Information Display
CHCMB (Chassis Control Module B) - Basic Function DTC Analysis Data Analysis ECU Information Display	EPICD (Electric Power Inverter Converter Control Module 'D') - Basic Function DTC Analysis Data Analysis ECU Information Display
DADC_2 (Driver Assistance Domain Controller) - Basic Function DTC Analysis Data Analysis ECU Information Display	EPICE (Electric Power Inverter Converter Module 'E') - Basic Function DTC Analysis Data Analysis ECU Information Display
DDCM (Driveline Disconnect Control Module) - Basic Function DTC Analysis Data Analysis ECU Information Display	FARC (Front Active Roll Control Module) - Basic Function DTC Analysis Data Analysis ECU Information Display
DDM (Driver's Door Module) - Basic Function DTC Analysis Data Analysis ECU Information Display - Special Function Driver Front Door Glass Calibration	GSM (Gear Shift Module) - Basic Function DTC Analysis Data Analysis ECU Information Display
DRDM (Driver's Rear Door Module) - Basic Function DTC Analysis Data Analysis ECU Information Display - Special Function Driver Rear Door Glass Calibration	GWM (Gateway Module) - Basic Function DTC Analysis Data Analysis ECU Information Display
DSM (Driver's Seat Module) - Basic Function DTC Analysis Data Analysis ECU Information Display	HCM (Headlamp Control Module) - Basic Function DTC Analysis Data Analysis ECU Information Display
EESM (Electrical Energy Storage Module) - Basic Function DTC Analysis Data Analysis ECU Information Display	HCMB (Headlamp Control Module B) - Basic Function DTC Analysis Data Analysis ECU Information Display
EPIC (Electric Power Inverter Converter Module) - Basic Function DTC Analysis Data Analysis	HUD (Head up Display) - Basic Function DTC Analysis Data Analysis ECU Information Display
	HVAC (Heating Ventilation and Air Conditioning Control Module) - Basic Function DTC Analysis

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

Data Analysis
ECU Information Display

ICCM (Infotainment Compute Control Module)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

ICCMB (Infotainment Compute Control Module 'B')
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

ICIMA (Interactive Control Interface Module 'A')
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

IDMA (Interactive Display Module A)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

IGM (Infotainment Gateway Module)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

IGMB (Infotainment Gateway Module 'B')
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

IPCB (Instrument Panel Cluster Control Module B)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

IPMA (Image Processing Control Module A)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

LIDM (Rear Left Display)
- Basic Function
DTC Analysis
ECU Information Display

NFSM (Near Field Sensing Module)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

OCS (Restraints Occupant Classification System Module)
- Basic Function
DTC Analysis
ECU Information Display

PCM (Powertrain Control Module)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
- Special Function
Service Message Reset
Allow Central Configuration Data Learning
Factory Speed Limit - Disable / Enable
Fuel Prime
Fuel Tank Smoke Test
Idle Speed
Particulate Filter Regeneration
Reset All Adaptions
Throttle Valve Actuator Replacement

PCMB (Powertrain Control Module B)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

PDM (Passenger's Door Module)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

PRDM (Passenger's Rear Door Module)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

PSCM (Power Steering Control Module)
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

PSCMB (Power Steering Control Module B)
- Basic Function

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

DTC Analysis
Data Analysis
ECU Information Display

PSM (Passenger's Seat Module)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

RARC (Rear Active Roll Control Module)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

RCM (Restraints Control Module)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

RDCM (Rear Differential Control Module)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

RFA (Remote Function Actuator)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

RGTM (Rear Gate/Trunk Module)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

RGTMB (Rear Gate Trunk Module B)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

RIDM (Rear Right Display)

- Basic Function

DTC Analysis
ECU Information Display

RSCM (Rear Wheel Steering Control Module)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

SASM (Steering Angle Sensor Module)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

SBU (Starter Battery Unit)

- Basic Function
DTC Analysis
ECU Information Display

SCMC (Seat Control Module C)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

SCMD (Seat Control Module D)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

SODL (Side Object Detection - Left)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

SODR (Side Object Detection - Right)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

SPMA (Seatbelt Pretensioner Control Module A)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

SPMB (Seatbelt Pretensioner Control Module B)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

TCCM (Transfer Case Control Module)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

TCM (Transmission Control Module)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

TCU (Telematic Control Unit Module)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

TPM (Tyre Pressure Monitoring System)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

WDCM (Wireless Device Charger Module)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

Range Rover Sport (DoIP) 2023~ : AUS

- PCM (Powertrain Control Module)
- Basic Function
- DTC Analysis
- ECU Information Display
- Special Function
- Service Message Reset
- Diesel Exhaust Fluid Injection Pump Replacement
- Diesel Exhaust Fluid Level Check
- Diesel Exhaust Fluid Prime and Pressure Test
- Diesel Exhaust Fluid Tank Level Sensor Replacement
- Diesel Particulate Filter Differential Pressure Sensor Replacement
- Diesel Particulate Filter Soot Mass Level Check

New function added

Range Rover Sport 2017 : AUS

- PCM (Powertrain Control Module)
- Special Function
- Diesel Particulate Filter Dynamic Regeneration
- Particulate Filter Replacement

Range Rover Sport 2014 : UAE

- CHCM (Chassis Control Module)

- Special Function
- Air-suspension deflation
- Air-suspension inflation
- Set/un-set air suspension geometry set-up

Discovery 4 (LR4) 2012~2013 : KOR

- PCM (Powertrain Control Module)

- Special Function
- Injector Replacement

Feedback

- KOR : Discovery 4 2012 Function added
- KOR : Discovery 2017 PCM ID added
- KOR : Discovery 2018 PCM ID added
- AUS : Discovery Sport 2019 PCM ID added
- AUS : Discovery Sport 2021 PCM ID added
- PNA : Range Rover 2023 IPMA Bug fixed
- UAE : Range Rover Sport 2014 Function added
- AUS : Range Rover Sport 2017 ID added
- AUS : Range Rover Sport 2023 PCM Bug fixed
- AUS : Range Rover Sport 2024 Model added
- KOR : Range Rover Velar 2018 ABS Bug Fixed
- KOR : Range Rover Velar 2020 ABS ID added

[Back to Index](#)

JAGUAR

Bug Fixed

I-Pace (DoIP) 2020

- IPMA (Image Processing Control Module A)
- Special Function
- Camera Calibration

[Back to Index](#)

MERCEDES BENZ

New model added

CLA 174

CLA 178

BM48

- Basic Function
- DTC Analysis
- ECU Information

HERMES

- Basic Function
- DTC Analysis
- ECU Information

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

DHLS-CU-VR - Basic Function DTC Analysis ECU Information	ECU Information
LIN : PTC heater booster - Basic Function DTC Analysis ECU Information	ABA/DTR - Basic Function DTC Analysis ECU Information
LIN : LCP - Basic Function DTC Analysis ECU Information	IRS-HLA - Basic Function DTC Analysis ECU Information
T-Class 420	ES - Basic Function DTC Analysis ECU Information
IC - Basic Function DTC Analysis ECU Information	AAC - Basic Function DTC Analysis ECU Information
ZAN - Basic Function DTC Analysis ECU Information	SAM - Basic Function DTC Analysis ECU Information
ZGW-ZF - Basic Function DTC Analysis ECU Information	Fuse and relay modules - Basic Function DTC Analysis ECU Information
RFK - Backup camera - Basic Function DTC Analysis ECU Information	PARKTRONIC - Basic Function DTC Analysis ECU Information
LRE - Basic Function DTC Analysis ECU Information	SRS - Basic Function DTC Analysis ECU Information
HVAC - Basic Function DTC Analysis ECU Information	HFM - Basic Function DTC Analysis ECU Information
Sound generator for electric vehicle - Basic Function DTC Analysis ECU Information	Inductive charging system - Basic Function DTC Analysis ECU Information
FAGW - Basic Function DTC Analysis	SG-FAS - Basic Function DTC Analysis

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

ECU Information

IRS-HRA

- Basic Function
- DTC Analysis
- ECU Information

PSM

- Basic Function
- DTC Analysis
- ECU Information

Monitoring of DC charging

- Basic Function
- DTC Analysis
- ECU Information

MFK

- Basic Function
- DTC Analysis
- ECU Information

ME/CDI

- Basic Function
- DTC Analysis
- ECU Information

ETC

- Basic Function
- DTC Analysis
- ECU Information

ESP(R)

- Basic Function
- DTC Analysis
- ECU Information

CGW

- Basic Function
- DTC Analysis
- ECU Information

PTCU

- Basic Function
- DTC Analysis
- ECU Information

BMS-A

- Basic Function
- DTC Analysis
- ECU Information

BMS-B

- Basic Function
- DTC Analysis

ECU Information

SCR

- Basic Function
- DTC Analysis
- ECU Information

SCM

- Basic Function
- DTC Analysis
- ECU Information

AC charger for high-voltage battery

- Basic Function
- DTC Analysis
- ECU Information

SG-EM

- Basic Function
- DTC Analysis
- ECU Information

G-Class 465

BMS

- Basic Function
- DTC Analysis
- ECU Information

ADS

- Basic Function
- Data Analysis
- ECU Information

DCCU

- Basic Function
- Data Analysis
- ECU Information

SG-EM

- Basic Function
- Data Analysis
- ECU Information

48 V battery

- Basic Function
- Data Analysis
- ECU Information

ADS

- Basic Function
- Data Analysis
- ECU Information

LBM

- Basic Function

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

Data Analysis
ECU Information

New system added

G-Class 464 Emergency override system

- Basic Function
DTC Analysis
ECU Information

G-Class 464 User interface Control Unit

- Basic Function
DTC Analysis
ECU Information

New function added

E-Class 213 ETC

- Basic Function
Data Analysis

S-Class 223 EZS

- Basic Function
Actuation Test

S-Class 223 ME/CDI

- Basic Function
Actuation Test
- Special Function
Display of SCN
Display of CVN
Display of model check number
Resetting of values for sensor rotor adaptation
Reset of mixture adaptation values
Reset learned values
Enabling of engine start after crash event
Activation of fuel pump
Teach-in of throttle valve end stops
Perform teach-in process Sensor rotor adaptation

Sprinter 906 ESP

- Basic Function
Actuation Test
- Special Function
ABS solenoid valve with roller dynamometer
ABS solenoid valve without roller dynamometer
ASR operational check

Sprinter 907 ABS/ESP

- Special Function
Variant Coding (Customize)

Sprinter 907 SCR

- Special Function
R7/3 (AdBlue(R) pressure line heating element)
A103r1 (AdBlue(R) tank heating element)

Feedback

Korea : V-447 Engine bug fixed
Korea : S-223 ABS/ESP Special Function bug fixed
Korea : E-213 Engine Data Display item added
Korea : E-213 TPM Special Function bug fixed
Korea : CLA-118 ETC Data Display item added
Australia : Sprinter 907 ABS Special Function added
Australia : E-213 ETC Special Function bug fixed
Australia : Sprinter 906 ABS Special Function bug fixed
UAE : C-205 Engine Data Display item added
UAE : Sprinter 906 ABS Actuation Test added
UAE : B-245 Engine bug fixed
UAE : V-639 Engine Data Display bug fixed
USA : Sprinter 907 SCR Special Function added

[Back to Index](#)

FIAT/ALFA ROMEO/LANCIA

New system added

500

EAC(Electric A/C Compressor)
- Basic Function
DTC Analysis
Data Analysis
ECU Information

ETM(Entertainment telematic module)

- Basic Function
DTC Analysis
Data Analysis
Actuation Test
ECU Information
- Special Function
Audio Test Subwoofer Specific
EOL Audio Test
Touch Screen Test
AV Signal Detection
Power Down
Disable User Inputs
Reset Parameters to Default

Ducato Facelift

SCR(M)(Selective Catalytic Reduction Module)

- Basic Function
DTC Analysis
Data Analysis
ECU Information
- Special Function
Anti sticking for Injector 1
Anti sticking for Injector 2
Extended Purge

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

Performance Injector 1
Performance Injector 2
Replacement of the Control Unit
Replacement of the Injector 1
Replacement of the Injector 2
Replacement of the Pressure Sensor
Replacement of the Pump
Replacement of the Tank
Replacement of the Tube
Reset of the first filling
Reset of the Injector 1
Reset of the Injector 2
Reset of the Pump
Reset of the Tank
System quality control
Test for the leakages control
Test for the Pump performance
Test of Injector 1 noise
Test of Injector 2 noise
Test of Purge
Test of the Tank heat
Test of the Tube heat

RFH(Radio Frequency Hub)

- Basic Function
DTC Analysis
Data Analysis
Actuation Test
ECU Information
- Special Function
Clear events log to Passive Entry / Remote Control and Uconnect
RFH immobilizer antenna test

TPM(Tire pressure module)

- Basic Function
DTC Analysis
Data Analysis
Actuation Test
ECU Information
- Special Function
TPM Sensor Rolls Test
Clear TPM Sensor Rolls Test Results
Program Left Front Tire Sensor ID
Program Left Rear Tire Sensor ID
Program Right Front Tire Sensor ID
Program Right Rear Tire Sensor ID

Function improved

500e

EESM(External Engine Sound Synthesis Module)

- Basic Function
DTC Analysis
Data Analysis
Actuation Test

ECU Information
- Special Function
Output Short Test
Software Test
Tone Test

Ducato Facelift

ECM(Engine control module)

- Basic Function
DTC Analysis
Data Analysis
Actuation Test
ECU Information
- Special Function
EGR High Pressure Valve Test
EGR Low Pressure Valve Test
Engine Restart (Inducement Shutdown)
Glow plug preheating circuit test
HTR (High Temperature Radiator) cooling pump test
LTR (Low Temperature Radiator) cooling pump test
Mission profile Data
Reset Driven Distance With Fuel Lamp On
Reset Driven Distance With Water Temperature Lamp On
Speed Limit Setting
Stop&Start Data
Throttle Valve Test
Air Filter Replacement
Clutch group and or clutch potentiometer replacement
Control unit reprogramming (AFTER flashing)
Injector programming
Differential pressure sensor replacement (only for version with DPF)
EGR high pressure valve replacement
EGR low pressure valve replacement
Engine mechanical components or engine substitution (due for engine oil lack)
Fuel pump high pressure replacement
Intelligent Alternator (IAM) Replacement
Neutral Sensor Position Learning
NOx temperature sensor replacement (downstream SCR catalyst)
NOx temperature sensor replacement (midstream SCR catalyst)
NOx temperature sensor replacement (upstream SCR catalyst)
Oil change
Particulate filter (DPF) with integrated Selective Catalytic Reduction (SCR) replacement
Diesel Particulate Filter functions
Particulate matter sensor replacement
Rail pressure sensor replacement
Temperature Sensor Replacement (Inlet SCR Catalyst)
Whole Engine replacement (without ECU replacement)

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

[Back to Index](#)

PEUGEOT/CITROEN

New type added

207 (2006~2011)

Under-inflation detection

- DSG_UDS

208 (Ai91) (2015~)

Anti-theft alarm

- MUS

208 (P21) (2017~)

Gearbox

- DCT_6DCT200

301 (2017~)

Trailer relay unit

- BSG_2010_RQ

308 (T9) (2015~)

Engine

- V46_21

- CMM_VD56

- CMM_MG1CS042

Trailer relay unit

- BSG_2010_RQ

Anti-theft alarm

- MUS

407 (2004~2010)

Engine

- S2000PM2

- HDI_SID803A

Gearbox

- BVA_AM6_AT6_EURO5

508 RXH (2014~)

Under-inflation detection

- DSG

508 (R8) (2017~)

Power steering

- GEP

2008 (2013~)

Trailer relay unit

- BSG_2010_RQ

2008 (P24) (2017~)

Gearbox

- DCT_6DCT200

3008 (2009~)

Air conditioning

- TDC_RFTA_MUX

Under-inflation detection

- DSG_UDS

3008 (P84) (2017~)

Engine

- CMM_MD1CS003_EURO6_4

PARTNER/RIFTER (K9) (2018~)

Engine

- CMM_MD1CS003_EURO6_4

- CMM_MD1CS003_EURO5

RCZ (2010~2015)

Under-inflation detection

- DSG_UDS

EXPERT (2008~2015)

Engine

- HDI_SID803A

- MM6KP

- DCM3.5

ABS/ESP

- ESP81

- ABS8_BOSCH

- ESP8_BOSCH

Air conditioning

- CLUM_REGULEE

EXPERT (K0) (2016~)

Power steering

- GEP

TRAVELLER (2016~)

Power steering

- GEP

Service module/Independent telematic unit

- BTA_2

- BTA_3R

- BTA_3S

Engine

- CMM_MD1CS003_EURO6_4

C3 (B618) (2018~)

Service module/Independent telematic unit

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

- BTA_3R
- BTA_3S

C3 PICASSO (2009~)

- Engine
- VD46

C3 Aircross (Ai58) (2010~2020)

- Air conditioning
- CLUM_REGULEE

C3 Aircross (A88) (2017~)

- Service module/Independent telematic unit
- BTA_2
- BTA_3R

C4 II (2011~2015)

- Trailer relay unit
- BSG_2010_RQ

C4 L (B7) (2014~)

- Under-inflation detection
- DSG

- Telematic unit (RTx) or audio-navigation
- MRN
- NAC

C4 PICASSO (2005~2013)

- Engine
- DCM3.4
- MEV17_4_EURO4
- MEV17_4_EURO5
- MM6KP
- DCM3.5
- DCM3.5_BR2

C4 PICASSO (B78) (2012~)

- Telematic unit (RTx) or audio-navigation
- MRN
- RCC
- NAC

C4 SPACETOURER (B78) (2018~)

- Service module/Independent telematic unit
- BTA
- BTA_2
- BTA_3R

- Trailer relay unit
- BSG_2010_RQ

- Anti-theft alarm
- MUS

- Telematic unit (RTx) or audio-navigation
- MRN
- SMEG_PLUS

C4 Cactus E3 (2014~)

- Trailer relay unit
- BSG_2010_RQ

C4 Cactus F3 (2017~)

- Service module/Independent telematic unit
- BTA
- BTA_3R
- BTA_3S

- Trailer relay unit
- BSG_2010_RQ

C5 (X7) (2008~)

- Service module/Independent telematic unit
- BTA
- BTA_3R
- BTA_3S

- Engine
- EDC16CP39

C5 Aircross (2017~)

- Service module/Independent telematic unit
- BTA_CN

C-ELYSEE (2012~)

- Engine
- CMM_MD1CS003_EURO6_4

- ABS/ESP
- ABSMK100

DS3 (2010~)

- Telematic unit (RTx) or audio-navigation
- RADIONAV_RNEG
- RNEG2010

DS3 (A55P) (2017~)

- Air conditioning
- CLUM_REGULEE

- Service module/Independent telematic unit
- BTA_3R
- BTA_3S

DS4 (2011~)

- Under-inflation detection
- DSG

DS5 (2011~)

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

Under-inflation detection
- DSG

JUMPY/Dispatch (2009~2015)

Engine
- EDC17C10_BR2
- HDI_SID803A
- MM6KP
- DCM3.5

Gearbox
- BVA_AM6_AT6_EURO5

ABS/ESP
- ESP81
- ABS8_BOSCH
- ESP8_BOSCH

Berlingo (K9) (2018~)

Engine
- CMM_MD1CS003_EURO6_4
- CMM_MD1CS003_EURO5

Trailer relay unit
- BSG_2010_RQ

SPACETOURER (2016~)

Power steering
- GEP

Engine
- CMM_MD1CS003_EURO6_4

Anti-theft alarm
- MUS

New system added

207 (2006~2011)

Service module/Independent telematic unit
- BTA

208 (2012~2015)

Trailer relay unit
- BSG_2010_RQ

Anti-theft alarm
- MUS

208 (P21) (2017~)

Trailer relay unit
- BSG_2010_RQ

308 (2007~)

Under-inflation detection
- DSG_UDS

- DSG

Moving panel deflector
- DEFL_PAN_MOBIL

308 (T9) (2015~)

Service module/Independent telematic unit
- BTA
- BTA_2
- BTA_3R
- BTA_3S
- BTA_CN

408 (T73) (2010~2015)

Under-inflation detection
- DSG

508 (2011~2015)

Under-inflation detection
- DSG_UDS
- DSG

Trailer relay unit

- BSG_2010_RQ

508 RXH (2014~)

Trailer relay unit
- BSG_2010_RQ

508 (R8) (2017~)

Trailer relay unit
- BSG_2010_RQ

Anti-theft alarm
- MUS2

508L (R83) (2017~)

Under-inflation detection
- DSG_UDS

607R (2005~2010)

Under-inflation detection
- DSG

2008 (P24) (2017~)

Trailer relay unit
- BSG_2010_RQ

3008 (P84) (2017~)

Engine wiring housing
- BSM_2010

Trailer relay unit
- BSG_2010_RQ

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

Anti-theft alarm
- MUS2

5008 (2009~2016)
Under-inflation detection
- DSG_UDS
- DSG

Air conditioning
- CLUM_REGULEE

5008 (P87) (2016~)
Engine wiring housing
- BSM_2010

Trailer relay unit
- BSG_2010_RQ

Anti-theft alarm
- MUS2

PARTNER/RIFTER (K9) (2018~)
Trailer relay unit
- BSG_2010_RQ

Anti-theft alarm
- MUS2

PARTNER (B9) (2008~)
Under-inflation detection
- DSG_UDS
- DSG

PARTNER EV (B9e) (2015~)
Under-inflation detection
- DSG_UDS
- DSG

EXPERT (2008~2015)
Under-inflation detection
- DSG_UDS
- DSG

EXPERT (K0) (2016~)
Engine wiring housing
- BSM_2010

Trailer relay unit
- BSG_2010_RQ

Anti-theft alarm
- MUS

TRAVELLER (2016~)
Trailer relay unit

- BSG_2010_RQ

Anti-theft alarm
- MUS

C3 (B618) (2018~)
Trailer relay unit
- BSG_2010_RQ

C3 Aircross (A88) (2017~)
Trailer relay unit
- BSG_2010_RQ

Anti-theft alarm
- MUS2

C4 (2004~2011)
Under-inflation detection
- DSG

C4 II (2011~2015)
Under-inflation detection
- DSG_UDS
- DSG

Blind spot monitoring
- SAM

C4 PICASSO (2005~2013)
Under-inflation detection
- DSG

Separate instrument panel
- COMPTE_TOURS

Telematic unit (RTx) or audio-navigation
- RADIONAV_RNEG
- BOITIER_TÉLEMATIQUE
- RNEG2010

C4 PICASSO (B78) (2012~)
Engine wiring housing
- BSM_2010

Service module/Independent telematic unit
- BTA
- BTA_2
- BTA_3R
- BTA_3S

Trailer relay unit
- BSG_2010_RQ

Anti-theft alarm
- MUS

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

C4 SPACETOURER (B78) (2018~)

Engine wiring housing
- BSM_2010

C4 Cactus E3 (2014~)

Service module/Independent telematic unit
- BTA
- BTA_2
- BTA_3R
- BTA_3S

C5 (X7) (2008~)

Under-inflation detection
- DSG_UDS
- DSG

C6 (2005~2012)

Under-inflation detection
- DSG

C-ELYSEE (2012~)

Trailer relay unit
- BSG_2010_RQ

DS4 (2011~)

Trailer relay unit
- BSG_2010_RQ

DS5 (2011~)

Trailer relay unit
- BSG_2010_RQ

DS5 Hybrid 4 (2016~)

Trailer relay unit
- BSG_2010_RQ

JUMPY/Dispatch (K0) (2016~)

Engine wiring housing
- BSM_2010

Trailer relay unit
- BSG_2010_RQ

Anti-theft alarm
- MUS

JUMPY/Dispatch (2009~2015)

Air conditioning
- CLUM_REGULEE

Berlingo (K9) (2018~)

Anti-theft alarm
- MUS2

Berlingo (B9) (2008~)

Under-inflation detection
- DSG_UDS

SPACETOURER (2016~)

Trailer relay unit
- BSG_2010_RQ

Auto VIN enhanced

Feedback

UAE: C5 Aircross (2017~) Engine Special Function Bug fixes

UAE: C2 (2004~2010) Engine ID added

[Back to Index](#)



New system type added

XC40 2024

ECM(Engine Control Module) – B420T4

- Basic Function

DTC Analysis

Data Analysis

Actuation Test

- Special Function

Activation of fuel pump in tank

Resetting adaptations for the fuel pump (low pressure side)

Resetting adaptations for the gasoline particulate filter

Resetting of adaptation values for the wastegate unit

Resetting of adaptation values for the low pressure

EGR valve

Resetting of adaptation values for the lambda probe, front

Resetting of adaptation values for the lambda probe, middle

Resetting of adaptation values for the lambda probe, rear

Resetting of adaptation values for the fuel injectors

Resetting of adaptation values for the flywheel

Resetting adaptations for cylinder balancing

Resetting adaptations for camshaft regulation, intake

Resetting adaptations for camshaft regulation, exhaust

TCM(Transmission Control Module) – 7DCTEVO FWD

- Basic Function

DTC Analysis

Data Analysis

Function improvement and bug fixes

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

DTC item added

[Back to Index](#)

AutoVIN improved

~ 2021 All models : Function improved
BCM2 – Brake Control Module 2
Parking brake service position

2022 ~ 2024 All models : Function improved
FLC2 - Forward Looking Camera 2
Calibration of forward looking camera (FLC2)

[Back to Index](#)

CHRYSLER/JEEP/DODGE

System added

TOWN/COUNTRY

DVD

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information
- Special Function
- ECU reset

PACIFICA

VRM (Video Routing Module)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information
- Special Function
- ECU reset

PROMASTER

EMCM (Entertainment Multimedia Control Module)

- Basic Function
- DTC Analysis
- ECU Information

FTM (Fleet Telematics Module)

- Basic Function
- DTC Analysis
- ECU Information

Feedback

USA : Journey – Automatic Gearbox Function Enhanced

PNA : Hornet – Haptical Lane Feedback Function Enhanced

PNA : Ram 1500 DT – 2026my added

AUS : Grand Cherokee – ABS Initialization Enhanced

OPEL/VAUXHALL

New model added

Grandland X 2018

Engine Control Module 1.2L(LES)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display
- Actuation Test
- Special Function
- Misfire Data
- Total Engine Overspeed Time Reset
- Battery Reconnect Detected Flag Reset
- Stop/Start Mode
- Knock Counter Reset 1
- Knock Counter Reset 2
- Knock Counter Reset 3
- Knock Counter Reset 4
- Accelerator Pedal Replacement Procedure
- Battery Replacement Procedure
- Clutch Replacement Procedure
- Cylinder Head Replacement Procedure
- Engine Replacement Procedure
- Exhaust Manifold Replacement Procedure
- Flywheel Replacement Procedure
- Fuel Injector Replacement Procedure
- Generator Replacement Procedure
- Intake/Exhaust Camshaft Position Actuator Replacement Procedure
- Throttle Body Replacement Procedure
- Turbocharger Actuator Replacement Procedure
- Turbocharger Replacement Procedure

Engine Control Module 1.5L(LQJ)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display
- Actuation Test
- Special Function
- Active Grille Air Shutter Learn
- Battery Learn
- Cylinder 1~4 Injector Flow Identifier
- DPF Pressure Sensor Learn
- DPF Regeneration
- EGR Valve Learn
- Flywheel Learn
- High Pressure Fuel Pump Learn
- Intake Air Flow Pump Learn

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

MAF Sensor Learn
Reductant Injector Learn
Reductant Pump Learn
Turbocharger Learn
Accessory Drive Belt Tensioner Wear Counter Reset
Clutch Pedal Position Sensor Reset
DPF Reset
Generator Learned Values Reset
Neutral Position Sensor Reset
NOx Sensor 1 Reset
NOx Sensor 2 Reset
Fuel Rail Pressure Relief Valve Activation Counter
Reset
Reductant Fluid Tank Level Reset
Reductant System Reset
Stop_Start Mode

Engine Control Module 1.5L(LQP)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
Actuation Test
- Special Function
Active Grille Air Shutter Learn
Battery Learn
Cylinder 1~4 Injector Flow Identifier
DPF Pressure Sensor Learn
EGR Valve Learn
Flywheel Learn
High Pressure Fuel Pump Learn
Intake Air Flow Pump Learn
MAF Sensor Learn
Reductant Injector Learn
Reductant Pump Learn
Accessory Drive Belt Tensioner Wear Counter Reset
Clutch Pedal Position Sensor Reset
DPF Reset
Generator Learned Values Reset
Neutral Position Sensor Reset
NOx Sensor 1 Reset
NOx Sensor 2 Reset
Fuel Rail Pressure Relief Valve Activation Counter
Reset
Reductant Fluid Tank Level Reset
Reductant System Reset
Stop_Start Mode

Engine Control Module 1.6L (LDI)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
Actuation Test
- Special Function

High Pressure Fuel Pump Learn
Flywheel Learn
Battery Learn
Intake Air Flow Pump Learn
EGR Valve Learn
Cylinder 1~4 Injector Flow Identifier
Turbocharger Learn
Fuel-Borne Catalyst Tank Level Reset
Catalyst Reset
NOx Catalyst Reset
NOx Sensor Reset
Reductant Injector Reset
Fuel Trim Reset
Reductant Fluid Tank Level Reset
Clutch Pedal Switch 'No Signal' Counter Reset
Engine Wear Counter Reset
Reductant System Reset
DPF Reset
Stop_Start Mode

Engine Control Module 1.6L (LHI)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
Actuation Test
- Special Function
Throttle Position Learn
Turbocharger Learn
Flywheel Learn
Fuel Injector Replacement Procedure
Learned Values Reset
Exhaust Aftertreatment System
Turbocharger Wastegate Learned Values Reset
Cylinder Head Learned Values Reset
Battery Learned Values Reset
Generator Learned Values Reset
Starter Activation Counter Reset
Total Engine Overspeed Time Reset
Battery Reconnect Detected Flag Reset

Engine Control Module 2.0L (LCI)

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
Actuation Test
- Special Function
Battery Learn
Camshaft Learn
DPF Pressure Sensor Learn
EGR Valve Learn
Flywheel Learn
Fuel-Borne Catalyst Pump Learn
Fuel Rail Pressure Regulator Learn

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

Fuel Rail Pressure Sensor or Fuel Rail Learn
High Pressure Fuel Pump Learn
High Pressure Fuel System Learn
Intake Air Flow Valve Learn
MAF Sensor Learn
Reductant Injector Learn
Reductant Pump Learn
Starter/Generator Learn
Turbocharger Learn
Accessory Drive Belt Wear Counter Reset
Battery Reconnect Detected
Battery State of Charge Reset
Cylinder Head Wear Counter Reset
DPF Reset
Engine Block Wear Counter Reset
Engine Wear Counter Reset
Exhaust Manifold Wear Counter Reset
NOx Adsorber Catalyst Reset
NOx Sensor 1 Reset
NOx Sensor 2 Reset
Power Supply Transformer Reset
Reductant Fluid Tank Level Reset
Reductant System Reset
Stop/Start Capacitor State of Health Reset
Stop/Start Mode

Frontview Camera - Windshield

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
- Special Function
Camera Calibration

Electronic Brake Control Module

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
Actuation Test
- Special Function
Longitudinal Acceleration Sensor Learn
Park Brake Calibration
Left Park Brake Actuator Reset
Right Park Brake Actuator Reset
Left Rear Brake Caliper Piston Reset
Right Rear Brake Caliper Piston Reset
Automatic Park Brake Apply Function

Power Steering Control Module

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
Actuation Test

Body Control Module

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
Actuation Test
- Special Function
Showroom Mode
Engine Oil Life Reset
Reset Driver Assistance Systems after Impact
Detection
Fuel Gauge Update

Traction Control Switch

- Basic Function
Data Analysis
Actuation Test

Auxiliary Body Control Module

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
Actuation Test

Inflatable Restraint Sensing and Diagnostic Module

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

Passenger Seat Belt Indicator

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
Actuation Test

Instrument Cluster- Basic Function

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
Actuation Test

HVAC Controls

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
Actuation Test

Video Processing Control Module

- Basic Function

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

DTC Analysis
Data Analysis
ECU Information Display
Actuation Test
- Special Function
Front Camera Alignment Learn
Rear Camera Alignment Learn

System comm. Stabilized
DTC item added
Sensor item added

[Back to Index](#)

HYUNDAI/GENESIS/SEASALL

Rain/Ambient Light Sensor Module

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

HVAC Control Module

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
Actuation Test

Left Steering Wheel Controls Switch

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
Actuation Test

Parking Assist Control Module

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display

Steering Column Control Module

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
Actuation Test

Battery Sensor Module

- Basic Function
Data Analysis
ECU Information Display

New model added

HYUNDAI USA

- GV70 Electrified(JK1 EV) 26
- GV70 electrified(JK1a EV) 26
- GV70(JK1) 26
- GV70(JK1a) 26
- G80 electrified(RG3 EV) 26
- GV60(JW1 EV) 26

HYUNDAI General

- MUFASA(NU2) 25~26
- GV70 electrified(JK1 EV) 25~26
- GV60(JW1 EV) 26
- CRETA(SU2b) 25~26
- CRETA(SU2id)25~26
- CRETA(SU2i)/ALCAZAR(PS7i) 25~26
- KONA(SX2) 26
- HB20(BR2) 26
- IONIQ 6(CE1g) 24~26

HYUNDAI Korea

- GV60(JW1 EV) 26
- GV70 electrified(JK1 EV) 25~26
- IONIQ 6 N(CE EV N) 26

GENESIS USA

- GV70 Electrified(JK1 EV) 26
- GV70 electrified(JK1a EV) 26
- GV70(JK1) 26
- GV70(JK1a) 26
- G80 electrified(RG3 EV) 26
- GV60(JW1 EV) 26

GENESIS General

- GV70 electrified(JK1 EV) 25~26
- GV60(JW1 EV) 26

[Back to Index](#)

[Back to Index](#)

HOLDEN

KIA

Function improvement and bug fixes

New model added

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

KIA General

- K8(GL3) 25~26
- K8 HEV(GL3 HEV) 25~26
- PV5(SW1K) 26
- EV9(MV) 25~26
- EV5(OV1k) 26
- EV4(CT1) 26
- SPORTAGE HEV(NQ5 HEV) 25~26
- SPORTAGE HEV(NQ5E HEV) 26

KIA Korea

- PV5(SW1K) 26
- EV3(SV1) 26
- SORRENTO HEV(MQ4 HEV) 26
- SORRENTO (MQ4) 26
- EV5(OV1k) 26
- EV9(MV) 24~26
- EV4(CT1) 26
- K8 HEV(GL3 HEV) 25~26
- K8(GL3) 25~26

[Back to Index](#)

SSANGYONG

New system added

MUSSO(GRAND)

AIRBAG

- Basic Function
 - DTC Analysis
 - Data Analysis
 - ActuationTest
 - System Identification
- Special Function
 - AIRBAG ECU Exchange
 - AIRBAG Variant Coding
 - AIRBAG Auto Variant Coding

CGW(CAN Gateway) - KOR/GEN

- Basic Function
 - DTC Analysis
 - System Identification
- Special Function
 - CGW Variant Coding

CGW(CAN Gateway) - EU

- Basic Function
 - DTC Analysis
 - System Identification
- Special Function
 - CGW Variant Coding

ECM(Engine Control Module) - D22DTR-EU6e

- Basic Function
 - DTC Analysis
 - Data Analysis
 - ActuationTest
 - System Identification
- Special Function
 - ECU Replace
 - Engine Variant Coding
 - Engine Multi Calibration
 - Injector Coding
 - Hydraulic static test
 - IMV Dynamic Test
 - Rail pressure control(Dynamic test)
 - Injector tip leak test
 - Injector correction
 - Injector correction (Driving)
 - CDPF Regeneration(Idle)
 - CDPF Regeneration(Driving)
 - LNT desulfurization
 - Pressure sensor replacement
 - PM sensor regeneration(Idle)
 - LNT+DPF Replacement
 - LNT+DPF Regeneration Information
 - Front wide band oxygen sensor learning reset
 - Rear wide band oxygen sensor learning reset
 - Front wide band oxygen sensor cleaning
 - Rear wide band oxygen sensor cleaning
 - SCR exchange initialization
 - SCR2 exchange initialization
 - SCR Doser exchange initialization
 - SCR2 Doser exchange initialization
 - SCR force start
 - Nox sensor exchange initialization
 - Nox0 sensor exchange initialization
 - Nox1 sensor exchange initialization
 - Nox2 sensor exchange initialization
 - Injector learning information
 - VIN Write
 - HP EGR Learning Reset
 - HP EGR initial learning
 - Throttle Initial Learn
 - RPC Reset
 - Air Flow Sensor(HFM) Reset
 - Cam/Crank Sensor Reset
 - Swirl Control Valve Initial Learn
 - VGT Initial Learn
 - Main Relay Reset
 - Stater operation count storage value initialization
 - EMS Registration
 - ISG Test

ECM(Engine Control Module) - G20DTR-EU6e

- Basic Function
 - DTC Analysis

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

Data Analysis
ActuationTest
System Identification
- Special Function
ECU Variant Set
Read Variant Coding
Write Variant Coding
Parameter Coding
VIN Write
EMS Registration
ECU Initialization
GPF Replacement
ECU Replacement
Service Regeneration

TCM(Transmission Control Module) - AISIN 6AT

- Basic Function
DTC Analysis
Data Analysis
ActuationTest
System Identification
- Special Function
TCU RESET

TCM(Transmission Control Module) - AISIN 8AT

- Basic Function
DTC Analysis
Data Analysis
ActuationTest
System Identification
- Special Function
TCU RESET

TCCU(4WD)

- Basic Function
DTC Analysis
Data Analysis
ActuationTest
System Identification

TGS(Transmission Gear Shift Lever)

- Basic Function
DTC Analysis
Data Analysis
ActuationTest
ECU Information Display
- Special Function
Lever Position Calibration

SBW(Shift by Wire)

- Basic Function
DTC Analysis
System Identification

SBWA(Shift by Wire Actuator)

- Basic Function
DTC Analysis
Data Analysis
ActuationTest
System Identification
- Special Function
N' Position Learn

ESC(Electronic Stability Control)

- Basic Function
DTC Analysis
Data Analysis
ActuationTest
System Identification
- Special Function
Air Bleeding
G-Sensor Initialization
Coding Initialization
Exhaust Gas Test Mode
TC valve air bleeding
ESC Variant Coding
Brake pad exchange

EPS(Electric Power Steering)

- Basic Function
DTC Analysis
Data Analysis
System Identification
- Special Function
Manual Variant Coding
EPS Torque Sensor Calibration

SAS(Streeng Angle)

- Basic Function
DTC Analysis
Data Analysis
System Identification
- Special Function
SAS Calibration

FCM(Front Camera Module)

- Basic Function
DTC Analysis
Data Analysis
System Identification
- Special Function
FCM Variant Coding
FCM Calibration Value
FCM Calibration
FCM Calibration(Driving correction)

FRM(Front Radar Module)

- Basic Function
DTC Analysis
Data Analysis

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

System Identification	
- Special Function	WPC(Wireless Power Control)
FRM Calibration	- Basic Function
FRM Service Calibration(Driving correction)	DTC Analysis
	Data Analysis
	System Identification
SDKM(Smart Digital Key Module)	
- Basic Function	DMS(Driver Monitoring System)
DTC Analysis	- Basic Function
Data Analysis	DTC Analysis
System Identification	System Identification
- Special Function	
LF ANT Check	ECALL(Emergency Call)
Smart Key Registration	- Basic Function
DKU VIN Write	DTC Analysis
ESCL Coding	System Identification
ESCL Registration	- Special Function
	Parameter coding(EU)
	Phone Number Save(EU)
BCM(Body Control Module)	
- Basic Function	DCU(Dosing Control Unit)
DTC Analysis	- Basic Function
Data Analysis	Data Analysis
ActuationTest	ActuationTest
System Identification	System Identification
- Special Function	- Special Function
BCM Variant Coding	Urea Initial Injection
TPMS Sensor Value	Urea system inspection
TPMS wheel module ID Coding	Urea Injector actuator test
TPMS Variant Coding	
REKES Key Coding	New function added
Transponder Registration	KORANDO e-MOTION
PAS Sensor Parameter Coding	AIRBAG
	- Special Function
	G-SENSOR CALIBRATION
HVAC(Heating Ventilation Air Conditioning)	
- Basic Function	MCU(Motor Control Unit) - MAHINDRA
DTC Analysis	- Basic Function
Data Analysis	Data Analysis
ActuationTest	
System Identification	BMS(Battery Manager System) – e-MOTION
	- Basic Function
GCU(Glowplug Control Unit)	ActuationTest
- Basic Function	- Special Function
ECU Information Display	Battery Heater option check
- Special Function	Battery Pack Barcode
Glowplug Learning	EWP Coolent Exchange Mode
Glowplug Learning Result	
Glowplug Target Temperature	LDC(Low DC-DC Convertor)
Glowplug Coding - Target Temperature	- Basic Function
	Data Analysis
BSD(Blind Spot Detection)	
- Basic Function	EGP(Electric Gear Parking)
DTC Analysis	- Basic Function
Data Analysis	ActuationTest
System Identification	
- Special Function	
BSD exchange initialization	

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

EBU(Electric Brake Unit) - Special Function Pedal Travel Sensor Calibration	- Basic Function DTC Analysis Data Analysis
SKM(Smart Key Module)-Mototec - Special Function SKM Variant Coding	BCM(Body Control Module) - Basic Function DTC Analysis
TIVOLI(VERY NEW) ECM(Engine Control Module) - G16DF - Special Function ISG Starter Motor Reset Evaporative Gas Leak Inspection	SKM(Smart Key Module) - Basic Function DTC Analysis Data Analysis - Special Function Smart Key Registration VIN Info Read ESCL Coding ESCL Registration
TIVOLI-XLV ECM(Engine Control Module) - G16DF - Special Function ISG Starter Motor Reset Evaporative Gas Leak Inspection	WPC(Wireless Power Control) - Basic Function DTC Analysis
Function improved and bug fixed ACTYON HEV AIRBAG - Basic Function DTC Analysis - Special Function G-SENSOR CALIBRATION	SBW(Shift by Wire) - Basic Function DTC Analysis
VCU(Vehicle Control Unit) - Basic Function DTC Analysis Data Analysis	GCU(Generator Control Unit) - Basic Function DTC Analysis
E_ECM(HEV Engine Control Module) - Basic Function DTC Analysis	BMS(Battery Manager System) - Basic Function DTC Analysis
MCU(Motor Control Unit) - Basic Function DTC Analysis	BSD(Blind Spot Detection) - Basic Function DTC Analysis
EBU(Electric Brake Unit) - Basic Function DTC Analysis Data Analysis ActuationTest - Special Function Brake pad exchange	AUTO AMP(HVAC) - Basic Function DTC Analysis
EPS(Electric Power Steering) - Basic Function DTC Analysis	SWVM(Seat Warmer Module) - Basic Function DTC Analysis
FCM(Front Camera Module)	EPB(Electronic Parking Brake) - Basic Function DTC Analysis
	ACTYON COUPE AIRBAG - Basic Function DTC Analysis

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

CGW(CAN Gateway)
- Basic Function
DTC Analysis

ECM(Engine Control Module) - G15DTF
- Basic Function
DTC Analysis
Data Analysis

ECM(Engine Control Module) - G15DTF-EU6e
- Special Function
Read Variant Coding
Write Variant Coding

TCM(Transmission Control Module)
- Basic Function
DTC Analysis

ESC(Electronic Stability Control)
- Basic Function
DTC Analysis
- Special Function
Manual Variant Coding

EPS(Electric Power Steering)
- Basic Function
DTC Analysis
- Special Function
Brake pad exchange

FCM(Front Camera Module) - ~24.04
- Basic Function
DTC Analysis
Data Analysis

FCM(Front Camera Module) - 24.04~
- Basic Function
DTC Analysis
Data Analysis

FRM(Front Radar Module) - ~24.04
- Basic Function
DTC Analysis

BCM(Body Control Module)
- Basic Function
DTC Analysis
ActuationTest

SKM(Smart Key Module)
- Basic Function
Data Analysis
- Special Function
Smart Key Registration
SKM Variant Coding

ESCL Coding
ESCL Registration

BSD(Blind Spot Detection)
- Basic Function
DTC Analysis

PTG(Power Tail Gate)
- Basic Function
DTC Analysis

AUTO AMP(HVAC)
- Basic Function
DTC Analysis

WPC(Wireless Power Control) - ~24.04
- Basic Function
DTC Analysis

WPC(Wireless Power Control) - 24.04~
- Basic Function
DTC Analysis

SBWA(Shift by Wire Actuator)
- Basic Function
DTC Analysis
Actuation Test

SBW(Shift by Wire)
- Basic Function
DTC Analysis

SWVM(Seat Warmer Module)
- Basic Function
DTC Analysis

TORRES HEV
AIRBAG
- Basic Function
DTC Analysis
- Special Function
G-SENSOR CALIBRATION

VCU(Vehicle Control Unit)
- Basic Function
DTC Analysis
Data Analysis

E_ECM(HEV Engine Control Module)
- Basic Function
DTC Analysis

MCU(Motor Control Unit)
- Basic Function
DTC Analysis

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

EBU(Electric Brake Unit) - Basic Function DTC Analysis ActuationTest - Special Function Brake pad exchange	SWVM(Seat Warmer Module) - Basic Function DTC Analysis
EPS(Electric Power Steering) - Basic Function DTC Analysis	EPB(Electronic Parking Brake) - Basic Function DTC Analysis
FCM(Front Camera Module) - Basic Function DTC Analysis Data Analysis	TORRES EVX AIRBAG - Basic Function DTC Analysis - Special Function G-SENSOR CALIBRATION
BCM(Body Control Module) - Basic Function DTC Analysis	VCU(Vehicle Control Unit) - Basic Function DTC Analysis
SKM(Smart Key Module) - Basic Function DTC Analysis Data Analysis - Special Function Smart Key Registration VIN Info Read ESCL Coding ESCL Registration	MCU(Motor Control Unit) - Basic Function DTC Analysis
WPC(Wireless Power Control) - Basic Function DTC Analysis	BMS(Battery Manager System)-~25.04 - Basic Function DTC Analysis Data Analysis
SBW(Shift by Wire) - Basic Function DTC Analysis	BMS(Battery Manager System)-25.04~ - Basic Function DTC Analysis Data Analysis
GCU(Generator Control Unit) - Basic Function DTC Analysis	PCM(PCM_OBC_LDC) - Basic Function DTC Analysis
BMS(Battery Manager System) - Basic Function DTC Analysis	SBW(Shift by Wire) - Basic Function DTC Analysis
BSD(Blind Spot Detection) - Basic Function DTC Analysis	EBU(Electric Brake Unit) - Basic Function DTC Analysis ActuationTest - Special Function Brake pad exchange
AUTO AMP(HVAC) - Basic Function DTC Analysis	EPB(Electronic Parking Brake) - Basic Function DTC Analysis
	EPS(Electric Power Steering) - Basic Function DTC Analysis

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

FCM(Front Camera Module) - Basic Function DTC Analysis Data Analysis	- Basic Function DTC Analysis
FRM(Front Radar Module) - Basic Function DTC Analysis	ECM(Engine Control Module) - G15DTF - Basic Function DTC Analysis Data Analysis
ADCU(Auto Driving Control Unit) - Basic Function DTC Analysis	ECM(Engine Control Module) - G15DTF-EU6e - Special Function Read Variant Coding Write Variant Coding
BSD(Blind Spot Detection) - Basic Function DTC Analysis	TCM(Transmission Control Module) - Basic Function DTC Analysis
BCM(Body Control Module) - Special Function PAS Sensor Parameter Coding	ESC(Electronic Stability Control) - Basic Function DTC Analysis - Special Function Brake pad exchange
SDKM(Smart Digital Key Module) - Basic Function DTC Analysis Data Analysis System Identification - Special Function Smartkey Coding DKU VIN Write ESCL Coding ESCL Registration	EPS(Electric Power Steering) - Basic Function DTC Analysis - Special Function Manual Variant Coding
PTGM(Power Tail Gate Unit) - Basic Function DTC Analysis	FCM(Front Camera Module) - ~24.04 - Basic Function DTC Analysis Data Analysis
EHVC(Electric HVAC) - Basic Function DTC Analysis	FCM(Front Camera Module) - 24.04~ - Basic Function DTC Analysis Data Analysis
HVAC(Heating Ventilating and Air Conditioning) - Basic Function DTC Analysis	FRM(Front Radar Module) - ~24.04 - Basic Function DTC Analysis
WPC(Wireless Power Control) - Basic Function DTC Analysis	BCM(Body Control Module) - Basic Function DTC Analysis ActuationTest
TORRES AIRBAG - Basic Function DTC Analysis	SKM(Smart Key Module) - Basic Function Data Analysis - Special Function Smart Key Registration SKM Variant Coding ESCL Coding
CGW(CAN Gateway)	

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

ESCL Registration	- Basic Function
PTG(Power Tail Gate)	DTC Analysis
- Basic Function	Data Analysis
DTC Analysis	OBC(Onboard Charger)
AUTO AMP(HVAC)	- Basic Function
- Basic Function	Data Analysis
DTC Analysis	SBW(Shift by Wire)
WPC(Wireless Power Control) - ~24.04	- Basic Function
- Basic Function	DTC Analysis
DTC Analysis	Data Analysis
WPC(Wireless Power Control) - 24.04~	EGP(Electric Gear Parking)
- Basic Function	- Basic Function
DTC Analysis	DTC Analysis
SBWA(Shift by Wire Actuator)	EBU(Electric Brake Unit)
- Basic Function	- Basic Function
DTC Analysis	DTC Analysis
Actuation Test	Data Analysis
SBW(Shift by Wire)	ActuationTest
- Basic Function	- Special Function
DTC Analysis	G-Sensor Initialization
SWVM(Seat Warmer Module)	Coding Initialization
- Basic Function	Pressure sensor calibration
DTC Analysis	Brake pad exchange
KORANDO e-MOTION	EPS(Electric Power Steering)
AIRBAG	- Basic Function
- Basic Function	DTC Analysis
DTC Analysis	Data Analysis
- Special Function	FCM(Front Camera Module)
G-SENSOR CALIBRATION	- Basic Function
CGW(CAN Gateway)	DTC Analysis
- Special Function	Data Analysis
CGW Variant Coding	- Special Function
VCU(Vehicle Control Unit)	FCM Variant Coding
- Basic Function	FCM Calibration Value
DTC Analysis	FCM Calibration
Data Analysis	FRM(Front Radar Module)
- Special Function	- Basic Function
VCU Registration	DTC Analysis
VCU Variant Coding	Data Analysis
MCU(Motor Control Unit) -MAHINDRA	- Special Function
- Basic Function	FRM Variant Coding
DTC Analysis	FRM Calibration
BMS(Battery Manager System)	BCM(Body Control Module)-Mototec
	- Basic Function
	Data Analysis
	ActuationTest
	- Special Function

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

TPMS Sensor Value
TPMS Variant Coding

CGW(CAN Gateway)
- Basic Function
DTC Analysis

BCM(Body Control Module)-Camtronics

- Basic Function
Data Analysis
ActuationTest
- Special Function
TPMS Sensor Value
TPMS Variant Coding

ECM(Engine Control Module) - D16DTF

- Basic Function
DTC Analysis
Data Analysis
- Special Function
VGT Initial Learn

SKM(Smart Key Module)-Mototec

- Basic Function
DTC Analysis
Data Analysis
- Special Function
Smart Key Registration
ESCL Registration

ECM(Engine Control Module) - D16DTF-LPEGR

- Basic Function
DTC Analysis
- Special Function
VGT Initial Learn

SKM(Smart Key Module)-Camtronics

- Basic Function
DTC Analysis
Data Analysis
- Special Function
Smart Key Registration
ESCL Coding
ESCL Registration

ECM(Engine Control Module) - G15DTF(2019)

- Basic Function
DTC Analysis
Data Analysis

ECM(Engine Control Module) - G15DTF(2020~)

- Basic Function
DTC Analysis
Data Analysis

WPC(Wireless Power Control)

- Basic Function
DTC Analysis

ECM(Engine Control Module) - G15DTF-EU6e

- Special Function
Read Variant Coding
Write Variant Coding

PTGM(Power Tail Gate Unit)

- Basic Function
Data Analysis

TCM(Transmission Control Module)

- Basic Function
DTC Analysis

EHVC(Electric HVAC)

- Basic Function
Data Analysis

ABS/ESP(Antilock Brake System/Electronic Stability Program)

- Basic Function
DTC Analysis
- Special Function
Brake pad exchange

DATC(FATC)

- Basic Function
DTC Analysis
Data Analysis

EPS(Electric Power Steering) - ~24.04

- Basic Function
DTC Analysis
Data Analysis

VESS(Virtual Engine Sound System)

- Basic Function
DTC Analysis

EPS(Electric Power Steering) - 24.04~

- Basic Function
DTC Analysis

KORANDO II(BEAUTIFUL)

AIRBAG

- Basic Function
DTC Analysis
Data Analysis

FCM(Front Camera Module) - ~24.04

- Basic Function
DTC Analysis

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

FCM(Front Camera Module) - 24.04~ - Basic Function DTC Analysis Data Analysis	Data Analysis
FRM(Front Radar Module) - ~24.04 - Basic Function DTC Analysis	BCM(Body Control Module) - D22DTF - Basic Function Data Analysis
BCM(Body Control Module) - Camtronics - Basic Function DTC Analysis ActuationTest	TPMS(Tire Pressure Monitoring System) - Basic Function Data Analysis - Special Function TPMS Coding
SKM(Smart Key Module) - Mototec - Basic Function Data Analysis	TIVOLI(VERY NEW) AIRBAG - Basic Function DTC Analysis
SKM(Smart Key Module) - Camtronics - Basic Function Data Analysis - Special Function Smart Key Registration SKM Variant Coding ESCL Coding ESCL Registration	CGW(CAN Gateway) - Basic Function DTC Analysis
PTG(Power Tail Gate) - Basic Function DTC Analysis	ECM(Engine Control Module) - D16DTF - Basic Function DTC Analysis Data Analysis - Special Function VGT Initial Learn
WPC(Wireless Power Control) - ~24.04 - Basic Function DTC Analysis	ECM(Engine Control Module) - G15DTF(2019) - Basic Function DTC Analysis Data Analysis
WPC(Wireless Power Control) - 24.04~ - Basic Function DTC Analysis	ECM(Engine Control Module) - G15DTF(2020~) - Basic Function DTC Analysis Data Analysis
FATC - Basic Function DTC Analysis	ECM(Engine Control Module) - G15DTF-EU6e - Special Function Read Variant Coding Write Variant Coding
KORANDO C ECM(Engine Control Module) - D20DTF - Basic Function Data Analysis	ECM(Engine Control Module) - G16DF - Basic Function DTC Analysis Data Analysis - Special Function ECU Replace
ECM(Engine Control Module) - D22DTF - Special Function VGT Initial Learn	TCM(Transmission Control Module) - Basic Function DTC Analysis
ECM(Engine Control Module) - G20 - Basic Function	ABS/ESP(Antilock Brake System/Electronic Stability

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

Program) - ~24.04

- Basic Function
- DTC Analysis

ABS/ESP(Antilock Brake System/Electronic Stability Program) - 24.04~

- Basic Function
- DTC Analysis

EPS(Electric Power Steering) - ~24.04

- Basic Function
- DTC Analysis
- Data Analysis

EPS(Electric Power Steering) - 24.04~

- Basic Function
- DTC Analysis

FCM(Front Camera Module) - 2.0

- Basic Function
- DTC Analysis

FCM(Front Camera Module) - 3.0

- Basic Function
- DTC Analysis

FCM(Front Camera Module) - 24.04~

- Basic Function
- DTC Analysis
- Data Analysis

BCM(Body Control Module) - Camtronics

- Basic Function
- DTC Analysis

SKM(Smart Key Module) - Mototec

- Basic Function
- Data Analysis

SKM(Smart Key Module) - Camtronics

- Basic Function
- Data Analysis
- Special Function
- Smart Key Registration
- SKM Variant Coding
- ESCL Coding
- ESCL Registration

WPC(Wireless Power Control) - ~24.04

- Basic Function
- DTC Analysis

WPC(Wireless Power Control) - 24.04~

- Basic Function
- DTC Analysis

FATC

- Basic Function
- DTC Analysis

TIVOLI-XLV

- ECM(Engine Control Module) - G16DF
- Special Function
- ECU Replace

ECM(Engine Control Module) - D16DTF

- Basic Function
- DTC Analysis

TPMS(Tire Pressure Monitoring System)

- Basic Function
- Data Analysis
- Special Function
- TPMS Coding

REXTON(ALL NEW)

AIRBAG

- Basic Function
- DTC Analysis
- Data Analysis

ECM(Engine Control Module) - D22DTR

- Special Function
- VGT Initial Learn

ECM(Engine Control Module) - D22TRP

- Basic Function
- DTC Analysis
- Special Function
- VGT Initial Learn

ECM(Engine Control Module) - D22DTR-EU6e

- Basic Function
- DTC Analysis
- Data Analysis
- Special Function
- ECU Replace
- Engine Variant Coding
- Injector Coding
- Pressure sensor replacement
- LNT+DPF Replacement
- Front wide band oxygen sensor learning reset
- Rear wide band oxygen sensor learning reset
- SCR exchange initialization
- SCR2 exchange initialization
- SCR Doser exchange initialization
- SCR2 Doser exchange initialization
- SCR force start
- Nox sensor exchange initialization
- Nox0 sensor exchange initialization

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

Nox1 sensor exchange initialization
Nox2 sensor exchange initialization
VIN Write
VGT Initial Learn
EMS Registration
Engine Multi Calibration
Injector tip leak test
Throttle Initial Learn
Swirl Control Valve Initial Learn

ECM(Engine Control Module) - G20DTR
- Special Function
Read Variant Coding

SBA(Shift by Wire) - ~24.04
- Basic Function
DTC Analysis

SBA(Shift by Wire) - 24.04~
- Basic Function
DTC Analysis

ABS/ESP(Antilock Brake System/Electronic Stability Program)
- Basic Function
DTC Analysis
- Special Function
Brake pad exchange

EPS(Electric Power Steering)
- Basic Function
DTC Analysis
- Special Function
Manual Variant Coding

FCM(Front Camera Module) - ~24.04
- Basic Function
DTC Analysis
Data Analysis

FCM(Front Camera Module) - 24.04~
- Basic Function
DTC Analysis
Data Analysis

FRM(Front Radar Module) - ~24.04
- Basic Function
DTC Analysis

SKM(Smart Key Module) - Camtronics
- Basic Function
DTC Analysis
Data Analysis
- Special Function
Smart Key Registration

ESCL Coding
ESCL Registration
SKM Variant Coding
SKM UNIT Coding

BCM(Body Control Module) - Camtronics
- Basic Function
DTC Analysis

HVAC(Heating Ventilation Air Conditioning)
- Basic Function
DTC Analysis

PTG(Power Tail Gate)
- Basic Function
DTC Analysis

BSD(Blind Spot Detection)
- Basic Function
DTC Analysis

WPC(Wireless Power Control) - ~24.04
- Basic Function
DTC Analysis

WPC(Wireless Power Control) - 24.04~
- Basic Function
DTC Analysis

PRA(Power Relay Assembly)
- Basic Function
DTC Analysis

REXTON(G4)
ECM(Engine Control Module) - D22DTR
- Special Function
VGT Initial Learn

ECM(Engine Control Module) - D22DTR-SCR
- Special Function
VGT Initial Learn

TPMS(Tire Pressure Monitoring System)
- Basic Function
Data Analysis
- Special Function
TPMS Coding

SKM(Smart Key Module)
- Special Function
Smart Key Registration

REXTON W
ECM(Engine Control Module) - D22DTR
- Special Function

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

VGT Initial Learn

- Special Function
Brake pad exchange

TPMS(Tire Pressure Monitoring System)

- Basic Function
Data Analysis
- Special Function
TPMS Coding

EPS(Electric Power Steering)
- Basic Function
DTC Analysis

REXTON II

ECM(Engine Control Module) - D2.0 C3I

- Basic Function
DTC Analysis

FCM(Front Camera Module)
- Basic Function
DTC Analysis
Data Analysis

ECM(Engine Control Module) - D2.7 C2I

- Basic Function
DTC Analysis

BCM(Body Control Module)
- Basic Function
DTC Analysis
- Special Function
PAS Sensor Parameter Coding

ECM(Engine Control Module) - D2.7 C3I

- Basic Function
DTC Analysis

SKM(Smart Key Module)
- Basic Function
DTC Analysis
Data Analysis
- Special Function
Smartkey Coding
DKU VIN Write
ESCL Coding
ESCL Registration

TPMS(Tire Pressure Monitoring System)

- Basic Function
Data Analysis
- Special Function
TPMS Coding

REXTON

ECM(Engine Control Module) - D2.7 C2I

- Basic Function
DTC Analysis

SBW(Shift by Wire)
- Basic Function
DTC Analysis

MUSSO EV

AIRBAG

- Basic Function
DTC Analysis
- Special Function
G-SENSOR CALIBRATION

BMS(Battery Manager System)
- Basic Function
DTC Analysis

VCU(Vehicle Control Unit)

- Basic Function
DTC Analysis

PCM(PCM_OBC_LDC)
- Basic Function
DTC Analysis

MCU_F(Front Motor Control Unit)

- Basic Function
DTC Analysis

HVAC(Heating Ventilating and Air Conditioning)
- Basic Function
DTC Analysis

MCU_R(Rear Motor Control Unit)

- Basic Function
DTC Analysis

SWVM(Seat Warmer Module)
- Basic Function
DTC Analysis

EBU(Electric Brake Unit)

- Basic Function
DTC Analysis
ActuationTest

EVCC(EV Charging Control)
- Basic Function
DTC Analysis

ADCU(Auto Driving Control Unit)
- Basic Function
DTC Analysis

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

EHVC(Electric HVAC)

- Basic Function
- DTC Analysis

MUSSO II(REXTON SPORTS)

AIRBAG

- Basic Function
- DTC Analysis
- Data Analysis

CGW(CAN Gateway)

- Basic Function
- DTC Analysis

ECM(Engine Control Module) - D22DTR

- Special Function
- VGT Initial Learn

ECM(Engine Control Module) - D22TRP

- Basic Function
- DTC Analysis
- Data Analysis
- Special Function
- VGT Initial Learn

ECM(Engine Control Module) - D22DTR-EU6e

- Basic Function
- DTC Analysis
- Data Analysis
- Special Function
- ECU Replace
- Engine Variant Coding
- Injector Coding
- Pressure sensor replacement
- LNT+DPF Replacement
- Front wide band oxygen sensor learning reset
- Rear wide band oxygen sensor learning reset
- SCR exchange initialization
- SCR2 exchange initialization
- SCR Doser exchange initialization
- SCR2 Doser exchange initialization
- SCR force start
- Nox sensor exchange initialization
- Nox0 sensor exchange initialization
- Nox1 sensor exchange initialization
- Nox2 sensor exchange initialization
- VIN Write
- VGT Initial Learn
- EMS Registration
- Engine Multi Calibration
- Injector tip leak test
- Throttle Initial Learn
- Swirl Control Valve Initial Learn

ECM(Engine Control Module) - G20DTR

- Special Function
- Read Variant Coding

TCM(Transmission Control Module)

- Basic Function
- DTC Analysis
- Data Analysis
- System Identification
- Special Function
- TCU RESET

TGS(Transmission Gear Shift Lever)

- Basic Function
- DTC Analysis
- Data Analysis
- Special Function
- Lever Position Calibration

ABS/ESP(Antilock Brake System/Electronic Stability Program)

- Basic Function
- DTC Analysis
- Data Analysis
- Special Function
- ABS Variant Coding

EPS(Electric Power Steering)

- Basic Function
- DTC Analysis
- Special Function
- Manual Variant Coding

SAS(Steering Angle)

- Basic Function
- DTC Analysis
- Data Analysis
- System Identification

FCM(Front Camera Module) - ~24.04

- Basic Function
- DTC Analysis
- Data Analysis

FCM(Front Camera Module) - 24.04~

- Basic Function
- DTC Analysis
- Data Analysis
- Special Function
- FCM Calibration(Driving correction)

SKM(Smart Key Module) - Camtronics

- Basic Function
- DTC Analysis
- Data Analysis

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

- Special Function
Smart Key Registration
ESCL Coding
ESCL Registration
SKM Variant Coding
SKM UNIT Coding

BCM(Body Control Module) - Mototec

- Basic Function
Data Analysis
ActuationTest

BCM(Body Control Module) - Camtronics

- Basic Function
DTC Analysis

HVAC(Heating Ventilation Air Conditioning)

- Basic Function
DTC Analysis

GCU(Glowplug Control Unit)

- Special Function
Glowplug Learning
Glowplug Learning Result
Glowplug Target Temperature
Glowplug Coding - Target Temperature

BSD(Blind Spot Detection)

- Basic Function
DTC Analysis
System Identification
- Special Function
BSD exchange initialization

DCU(Dosing Control Unit)

- Basic Function
Data Analysis
ActuationTest
- Special Function
Urea Injector actuator test

FRM(Front Radar Module)

- Basic Function
DTC Analysis
- Special Function
FRM Calibration
FRM Service Calibration(Driving correction)

MUSSO (REXTON SPORTS)

ECM(Engine Control Module) - D22DTR
- Special Function
VGT Initial Learn

ECM(Engine Control Module) - D22DTR-SCR

- Special Function

VGT Initial Learn

TPMS(Tire Pressure Monitoring System)

- Basic Function
Data Analysis
- Special Function
TPMS Coding

SKM(Smart Key Module) - new

- Special Function
Smart Key Registration

ACTYON SPORTS II

ECM(Engine Control Module) - D22DTR

- Special Function
VGT Initial Learn

TPMS(Tire Pressure Monitoring System)

- Basic Function
Data Analysis
- Special Function
TPMS Coding

ACTYON SPORTS

ECM(Engine Control Module) - D2.0 C3I

- Basic Function
DTC Analysis

ECM(Engine Control Module) - D2.0 C2I

- Basic Function
DTC Analysis

RODIUS/STAVIC II

ECM(Engine Control Module) - D22DTR
- Special Function
VGT Initial Learn

TPMS(Tire Pressure Monitoring System)

- Basic Function
Data Analysis
- Special Function
TPMS Coding

RODIUS

ECM(Engine Control Module) - D2.7 C3I

- Basic Function
DTC Analysis

ECM(Engine Control Module) - D2.7 C2I

- Basic Function
DTC Analysis

TPMS(Tire Pressure Monitoring System)

- Basic Function
Data Analysis

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

- Special Function
TPMS Coding

KYRON

ECM(Engine Control Module) - D2.0 C3I

- Basic Function
DTC Analysis

ECM(Engine Control Module) - D2.0 C2I

- Basic Function
DTC Analysis

ECM(Engine Control Module) - D2.7 C3I

- Basic Function
DTC Analysis

ECM(Engine Control Module) - D2.7 C2I

- Basic Function
DTC Analysis

CHAIRMAN W

TPMS(Tire Pressure Monitoring System) - TPMS

- Basic Function
Data Analysis
- Special Function
TPMS Coding

TPMS(Tire Pressure Monitoring System) - CGW

- Basic Function
Data Analysis
- Special Function
TPMS Coding

Function removed

KORANDO e-MOTION

BCM(Body Control Module)-Mototec

- Special Function
REKES Key Coding
Transponder Registration

BCM(Body Control Module)-Camtronics

- Special Function
REKES Key Coding
Transponder Registration

SKM(Smart Key Module)-Camtronics

- Special Function
SKM Variant Coding

[Back to Index](#)

MAHINDRA

New model added

FURIO_BS6

EMS

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
- Special Function
Speed Limit
Tyre Size
Vin (Vehicle Identification Number)
Injector Coding
AdBlue/DEF Metering
AdBlue/DEF Tank Level
Pressure Reduction
Particulate Filter Regeneration
Long Term Fuel Trim
Nitrogen Oxides Concentration (NOX)
Concentration of Ammonia (NH3) - Correction factor
Concentration of Ammonia (NH3) - Charge
SCR (Selective Catalytic Reduction) Replacement
Throttle Actuator On Intake Manifold
EGR Valve
Turbocharger Actuator
Exhaust Gas Throttle Actuator
AdBlue/DEF Dosing System - System Checking
AdBlue/DEF Dosing System - First Filling
AdBlue/DEF Dosing System - Preparation of
AdBlue/DEF Pressure
AdBlue/DEF Dosing System - System Drainage
AdBlue/DEF Circuit
Leakage Test
Static Test
Dosing Test
Fuel Pump
Throttle Actuator On Intake Manifold - Position
Throttle Actuator On Intake Manifold - Duty Cycle
EGR Valve - Position
EGR Valve - Duty Cycle
Turbocharger Actuator - Position
Turbocharger Actuator - Duty cycle
Fan
Air Conditioning Compressor - Actuator
Air Conditioning Compressor - Duty cycle
AdBlue/DEF Pump - Actuator
AdBlue/DEF Pump - Valve
AdBlue/DEF Return Solenoid Valve - Actuator
AdBlue/DEF Return Solenoid Valve - Relay
AdBlue/DEF Dosing System - Flow Direction Inverter
Valve

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

AdBlue/DEF Dosing System - AdBlue/DEF Dosing Valve

New type and function added

SCORPIO_S4

MBFM

- Special Function
- Write Vin
- Write Model Number

SCORPIO_S4-PLUS

MBFM

- Special Function
- Write Vin
- Write Model Number

ABS

- Special Function
- Write Vin
- Write Model Number

SCORPIO_S6

MBFM

- Special Function
- Write Vin
- Write Model Number

SCORPIO_S6-PLUS

MBFM

- Special Function
- Write Vin
- Write Model Number

ABS

- Special Function
- Write Vin
- Write Model Number

SCORPIO_S8

MBFM

- Special Function
- Write Vin
- Write Model Number

ABS

- Special Function
- Write Vin
- Write Model Number

SCORPIO_S10

ABS

- Special Function
- Write Vin
- Write Model Number

SCORPIO_S10-AT

ABS

- Special Function
- Write Vin
- Write Model Number

SCORPIO_S11

MBFM

- Special Function
- Write Vin
- Write Model Number

ABS

- Special Function
- Write Vin
- Write Model Number

SCORPIO_BS6

MBFM

- Special Function
- Write Vin
- Write Model Number

ABS

- Special Function
- Write Vin
- Write Model Number

SRS

- Special Function
- Write Model Number

SCORPIO-N_BS6

MBFM

- Special Function
- Write Vin
- Write Model Number

FOUR_WD

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

WLC

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

ICC

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

XYLO_D2

EMS
- Special Function
Write Vin
Write Model Number

XYLO_D4

EMS
- Special Function
Write Vin
Write Model Number

XYLO_E8

SRS
- Special Function
Write Vin

XYLO_E9

EMS
- Special Function
Write Vin
Write Model Number

SRS

- Special Function
Write Vin

XYLO_H4

EMS
- Special Function
Write Vin
Write Model Number

XYLO_H6

EMS
- Special Function
Write Vin
Write Model Number

XYLO_H8

EMS
- Special Function
Write Vin
Write Model Number

SRS

- Special Function
Write Vin

XYLO_H9

EMS
- Special Function
Write Vin
Write Model Number

SRS

- Special Function
Write Vin

BOLERO NEO_BS6

MBFM(HIGH)
- Special Function
Write Vin
Write Model Number

MBFM(MID)

- Special Function
Write Vin
Write Model Number

MBFM(BASE)

- Special Function
Write Vin
Write Model Number

ABS

- Special Function
Write Vin
Write Model Number

SRS

- Special Function
Write Vin
Write Model Number

BOLERO-POWERPLUS_BS6

MBFM
- Special Function
Write Vin
Write Model Number

ABS

- Special Function
Write Vin
Write Model Number

SRS

- Special Function
Write Vin
Write Model Number

XUV300

MBFM
- Special Function
Write Vin
Write Model Number

ABS

- Special Function

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

Write Vin
Write Model Number

XUV700_BS6
MBFM
- Special Function
Write Vin
Write Model Number

SRS
- Special Function
Write Vin
Write Model Number

XUV300_BS6
MBFM
- Special Function
Write Vin
Write Model Number

THAR_BS6
MBFM
- Special Function
Write Vin
Write Model Number

ABS
- Special Function
Write Vin
Write Model Number

ABS
- Special Function
Write Vin
Write Model Number

SRS
- Special Function
Write Vin
Write Model Number

SRS
- Special Function
Write Vin
Write Model Number

XUV500
ABS
- Special Function
Write Vin
Write Model Number

QUANTO_C8
SRS
- Special Function
Write Vin

SRS
- Special Function
Write Vin

QUANTO_C8_AMT
SRS
- Special Function
Write Vin

XUV500_BS6
ABS
- Special Function
Write Vin
Write Model Number

TUV300
EMS
- Special Function
Write Vin
Write Model Number

SRS
- Special Function
Write Vin

ABS
- Special Function
Write Vin
Write Model Number

GENIO
EMS
- Special Function
Write Vin
Write Model Number

SRS
- Special Function
Write Vin
Write Model Number

GENIOVX
EMS
- Special Function
Write Vin
Write Model Number

KUV100
EMS
- Special Function
Write Vin
Write Model Number

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

ABS
- Special Function
Write Vin
Write Model Number

SRS
- Special Function
Write Vin
Write Model Number

NUVOSPORT_N4
EMS
- Special Function
Write Vin
Write Model Number

NUVOSPORT_N4_PLUS
EMS
- Special Function
Write Vin
Write Model Number

ABS
- Special Function
Write Vin
Write Model Number

SRS
- Special Function
Write Vin

NUVOSPORT_N6
EMS
- Special Function
Write Vin
Write Model Number

ABS
- Special Function
Write Vin
Write Model Number

SRS
- Special Function
Write Vin

NUVOSPORT_N6_AMT
EMS
- Special Function
Write Vin
Write Model Number

ABS
- Special Function
Write Vin

Write Model Number

SRS
- Special Function
Write Vin

NUVOSPORT_N8
EMS
- Special Function
Write Vin
Write Model Number

ABS
- Special Function
Write Vin
Write Model Number

SRS
- Special Function
Write Vin

NUVOSPORT_N8_AMT
EMS
- Special Function
Write Vin
Write Model Number

ABS
- Special Function
Write Vin
Write Model Number

SRS
- Special Function
Write Vin

MARAZZO
MBFM
- Special Function
Write Vin
Write Model Number

ABS
- Special Function
Write Vin
Write Model Number

SRS
- Special Function
Write Vin
Write Model Number

JEETO_BS6
EMS
- Basic Function

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

DTC Analysis
Data Analysis
ECU Information Display

BLAZO_BS6

EMS
- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
- Special Function
Speed Limit
Tyre Size
Vin (Vehicle Identification Number)
Injector Coding
AdBlue/DEF Metering
AdBlue/DEF Tank Level
Pressure Reduction
Particulate Filter Regeneration
Long Term Fuel Trim
Nitrogen Oxides Concentration (NOX)
Concentration of Ammonia (NH3) - Correction factor
Concentration of Ammonia (NH3) - Charge
SCR (Selective Catalytic Reduction) Replacement
Throttle Actuator On Intake Manifold
EGR Valve
Turbocharger Actuator
Exhaust Gas Throttle Actuator
AdBlue/DEF Dosing System - System Checking
AdBlue/DEF Dosing System - First Filling
AdBlue/DEF Dosing System - Preparation of
AdBlue/DEF Pressure
AdBlue/DEF Dosing System - System Drainage
AdBlue/DEF Circuit
Leakage Test
Static Test
Dosing Test
Fuel Pump
Throttle Actuator On Intake Manifold - Position
Throttle Actuator On Intake Manifold - Duty Cycle
EGR Valve - Position
EGR Valve - Duty Cycle
Turbocharger Actuator - Position
Turbocharger Actuator - Duty cycle
Fan
Air Conditioning Compressor - Actuator
Air Conditioning Compressor - Duty cycle
AdBlue/DEF Pump - Actuator
AdBlue/DEF Pump - Valve
AdBlue/DEF Return Solenoid Valve - Actuator
AdBlue/DEF Return Solenoid Valve - Relay
AdBlue/DEF Dosing System - Flow Direction Inverter
Valve
AdBlue/DEF Dosing System - AdBlue/DEF Dosing
Valve

Function improvement and bug fixes

System Search Improved

SCORPIO_BS6

EMS
- Special Function
DNOX53 SCR Auto EOL Test

SRS

- Basic Function
DTC Analysis
Data Analysis
ECU Information Display
- Special Function
Write Vin

SCORPIO-N_BS6

EMS
- Special Function
DNOX53 SCR Auto EOL Test

BOLERO NEO_BS6

EMS
- Special Function
DNOX53 SCR Auto EOL Test

BOLEROPOWERPLUS_BS6

EMS
- Special Function
DNOX53 SCR Auto EOL Test

BOLEROPICKUP_BS6

EMS
- Special Function
DNOX53 SCR Auto EOL Test

XUV300_BS6

EMS
- Special Function
DNOX53 SCR Auto EOL Test

XUV700_BS6

EMS
- Special Function
DNOX53 SCR Auto EOL Test

EPS

- Special Function
SAS Calibration
SAS Decalibration

THAR_BS6

EMS
- Special Function
DNOX53 SCR Auto EOL Test

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

JEETO_BS6

EMS
- Special Function
DNOX53 SCR Auto EOL Test

SUPRO_BS6

EMS
- Special Function
DNOX53 SCR Auto EOL Test

SUPROMAXITRUCK_BS6

EMS
- Special Function
DNOX53 SCR Auto EOL Test

MARAZZO_BS6

EMS
- Special Function
DNOX53 SCR Auto EOL Test

SECURITY SYSTEM(India)_ALL MODEL

Immobilizer
- Special Function
Immo Sync (D16) (Only New ICU)

[Back to Index](#)

ASIAN TRUCKS

New function added

Traveller BS6 MD1C Engine
- Special Function
Particulate filter replacement (stage1)
Particulate filter replacement (stage2)

Function improvement and bug fixes

Unknown DTC added
Force CRUISER DELPHI(BS6)
TATA INTRA V10 800CC EMS

Function improved
Traveller BS6 MD1C Engine
- Special Function
Service Regeneration at Idle

[Back to Index](#)

MG

Function improvement and bug fixes

DTC item added
MG 3 (Australia) - EMS
MG 5 (AP32 TT) – TCM
MG RX8 (IS21) – ECM
MG eRX5 (AS24 MCE) – ECM
eMG 6 PHEV (IP32P CN6) -ECM
MG HS(AS23 TT) - ECM
MG HS(AS23 MCE) - ECM
MG RX8(IS21) - ECM
MG eRX5(AS24) - ECM
MG HS(AS23 UK) – PLCM

[Back to Index](#)

CHERY

New model added

OMODA 5 (T34)
- EMS (Engine Management System)
- CVT (Transmission Control Module)
- ABS/ESP (Anti-Lock Braking System/Electronics Stability Program)
- EPS (Electronic Power Steering)
- BCM (Body Control Module)
- TPMS (Tire Pressure Monitor System)
- SRS (Supplemental Restraint System)
- IHU (Infotainment Head Unit)
- ICM (Instrument Cluster Module)
- CLM (Climate Module)
- IMMO (Immobilizer)
- PEPS (Passive Entry and Passive Start System)
- RADAR (Radar Module)
- AVM (Around View Monitor Module)
- FCM (Front Camera Module)
- FRM (Front Radar Module)
- PLG (Power Lift Gate)
- CGW (Central Gateway)
- EGS (Electrical Gear Shifter)
- CWC (Cellphone Wireless Charger)
- AIPM/CCP (Automatic Air Conditioning Panel/Climate Control Panel)
- SHU1D (Row1 Driver Seat Heating Unit)
- SHU1P (Row1 Passenger Seat Heating Unit)
- DMS (Driving Monitor System)
- RLCR (Rear Left Corner Radar)
- RRRCR (Rear Right Corner Radar)

[Back to Index](#)

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

BYD

New model added

Seagull 2022~2024

ACC ((Nanjing Aotecar) Air Conditioning Compressor)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

AB1_BCM ((BYD) Rear body domain controller A_B1)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display
- Actuation Test

BMS ((BYD) battery management controller 400)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display
- Actuation Test
- Special Function
- Battery pack factory calibration
- Battery pack actual calibration
- One-click battery heating active test
- One-click battery cooling active test
- Electric leakage detection control switch OFF
- Hardwire interlock shielding

BMS300 ((BYD) battery management controller 300)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display
- Actuation Test
- Special Function
- Battery pack factory calibration
- Battery pack actual calibration
- One-click battery heating active test
- One-click battery cooling active test
- Electric leakage detection control switch OFF
- Hardwire interlock shielding

BMS320 ((BYD) battery management controller 320)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display
- Actuation Test
- Special Function

- Battery pack factory calibration
- Battery pack actual calibration
- One-click battery heating active test
- One-click battery cooling active test
- Electric leakage detection control switch OFF
- Hardwire interlock shielding

BSC ((BYD) Security system)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display
- Actuation Test
- Special Function
- Wheel bleeding
- EOL (End of Line) calibration
- Installation mode calibration
- Rack mode calibration
- Internal sensor calibration
- Tire pressure reset
- Erase the vehicle model configuration
- Write configuration of EQEB Comfort Y and Luxury Y
- Write configuration of EQEC-Noble Y (optional without ACC)
- Write configuration of EQEC-Noble Y (optional with ACC)
- Assembly detection line leakage detection function
- TMC leakage detection

CEPS1 ((SAIC) Power Steering_CEPS)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display
- Special Function
- Steering angle zero calibration
- Torque sensor standardisation

CEPS2 ((Longrun) Power steering_CEPS)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display
- Special Function
- Steering angle zero calibration
- XCP_Enable calibration
- Write configuration of EQEB Comfort Y and Luxury Y
- Write configuration of EQEC-Noble Y
- Write configuration of EQEC-Noble Y (optional LDA)

CEPS3 ((Nexteer) Power steering)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

- Special Function Steering angle zero calibration	Read VIN Initial after-sales calibration Write configuration of EQEC Noble Y Static calibration
DC_DC ((BYD) DC-DC Assembly (DD_DC_DC))	
- Basic Function DTC Analysis Data Analysis ECU Information Display	OBC ((BYD) On-board charger) - Basic Function DTC Analysis Data Analysis ECU Information Display
FMCU ((BYD) Front drive motor controller)	
- Basic Function DTC Analysis Data Analysis ECU Information Display	PTC ((SONGZ) Auxiliary Heating) - Basic Function DTC Analysis Data Analysis ECU Information Display
- Special Function Motor zero calibration	
BCMA ((BYD) Left body domain controller A_L1Pro)	SCPA ((Desay) Gear shift control mechanism panel assembly)
- Basic Function DTC Analysis Data Analysis ECU Information Display Actuation Test	- Basic Function DTC Analysis Data Analysis ECU Information Display
- Special Function Vehicle VIN writing and reading	
MPC_01 ((Bosch) Multi-function video controller)	SRS_01 ((BYD) Airbag)
- Basic Function DTC Analysis Data Analysis ECU Information Display	- Basic Function DTC Analysis Data Analysis ECU Information Display
- Special Function Read VIN Static calibration Dynamic calibration	- Special Function ECU unlocking Read VIN VIN Writing and airbag decryption
MPC_02 ((BYD) Multi-function video controller)	SRS_02 ((BYD) Airbag_RENESAS)
- Basic Function DTC Analysis Data Analysis ECU Information Display Actuation Test	- Basic Function DTC Analysis Data Analysis ECU Information Display
- Special Function Read VIN Static calibration Dynamic calibration Write calibration board information	- Special Function ECU unlocking Read VIN VIN Writing and airbag decryption
MPC_03 ((VALEO) Multi-function video controller)	VCU ((BYD) Vehicle Controller)
- Basic Function DTC Analysis Data Analysis ECU Information Display Actuation Test	- Basic Function DTC Analysis Data Analysis ECU Information Display
- Special Function	- Special Function Vehicle VIN writing and reading Roll angle offline calibration Cruise control configuration writing Adaptive cruise configuration writing

Więcej informacji pod numerem +48 601-817-201 I na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)

CS1 ((BYD) Multi-function switch)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

CS2 ((KOSTAL) combination switch)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

INS ((TYW) Combination Meter)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

Pad ((BYD) display bracket assembly)

- Basic Function
- ECU Information Display

SWS ((BYD) steering wheel switch)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display
- Actuation Test

WCT1 ((Beijing Invispower) wireless charging module)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

WCT2 ((Lin 'an Tianlong) Wireless charging module)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

INFC ((BYD) Interior PEPS controller)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display
- Actuation Test
- Special Function
- Transmission sequence check
- Update condition query
- Software and hardware consistency check

Media ((BYD) Multimedia System_Android)

- Basic Function
- DTC Analysis

ECU Information Display

SEC ((BYD) intelligent access controller)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display

SCPA2 ((BYD) Gearshift control mechanism panel assembly)

- Basic Function
- DTC Analysis
- Data Analysis
- ECU Information Display


[Back to Index](#)

ETC

Wydana nowa funkcja

[Przewodnik po DTC AI] (tylko Zenith Z7)

Dodano funkcję pozwalającą użytkownikom przeglądać informacje związane z DTC za pomocą AI




Więcej informacji pod numerem +48 601-817-201 | na www.gscan.com.pl

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)


[AI tłumacz] (tylko Zenith Z5,7, z wyjątkiem KOR)

Dodano funkcję wykorzystującą AI do tłumaczenia nieprzetłumaczonego tekstu w menu diagnostycznym, w tym DTC, czujniki i aktywne testy.





[Auto Scale Off] (tylko Zenith Z5,7)

Na ekranie wykresu dodano nowe pole wyboru "Auto Scale Off". Po włączeniu skala grafu pozostaje stała od tego momentu.



Ulepszony test gotowości (tylko Zenith Z5,7)

- Status gotowości po zatwierdzeniu DTC
- Status gotowości w bieżącym okresie jazdy




Analiza danych baterii (tylko Zenith Z7)


Dodano funkcję pomiaru oporu wewnętrznego poprzez funkcję rezystancji (dynamicznej). Zmierzone wyniki są wydawane w formacie raportu.

Zenith / Gscan Aktualizacja MAJ 2026

Dostępność niektórych funkcji może być różna w zależności od modelu testera (G2, G3, Z5, Z7)



Item name	Status	Max(V)	Min(V)	Disp(V)	Resis(mΩ)
Battery Cell Voltage 84	3.64	3.70	3.42	0.12	1.25
Battery Cell Voltage 85	3.64	3.70	3.40	0.12	1.25
Battery Cell Voltage 86	3.64	3.70	3.40	0.12	1.25
Battery Cell Voltage 87	3.64	3.70	3.44	0.10	1.11
Battery Cell Voltage 88	3.64	3.70	3.42	0.12	1.25
Battery Cell Voltage 89	3.64	3.70	3.40	0.12	1.25
Battery Cell Voltage 90	3.64	3.68	3.44	0.10	1.11
Battery Cell Voltage 91	3.64	3.70	3.42	0.12	1.25
Battery Cell Voltage 92	3.64	3.70	3.42	0.12	1.25
Battery Cell Voltage 93	3.64	3.70	3.42	0.12	1.25
Battery Cell Voltage 94	3.64	3.70	3.40	0.12	1.25
Battery Cell Voltage 95	3.64	3.70	3.40	0.12	1.25
Battery Cell Voltage 96	3.64	3.70	3.42	0.12	1.25



[Back to Index](#)

The main screen displays the following metrics:

SOC: 42.5 %

SOH: 99.8 %

Total Voltage: 698.1 V

Current Value: 0.0 A

Temperature: 13 °C

Average: 3.64V, Low value: 3.42V, High value: 3.86V, Number of Data: 192

A table below shows individual cell data with columns for Item name, Status, Max(V), Min(V), Disp(V), and Resis(mΩ).

